

# ***Digital Satellite Receiver***

---


Operating Instructions



***SAT-B1***

## WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of significant magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

### Caution

To prevent electric shock, do not use this polarized plug with an extension cord, receptacle, or other outlet unless the blades can be fully inserted to prevent blade exposure.

### Note to the CATV Installer

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

### Note to the DSS® Satellite Dish Installer

This reminder is provided to call the DSS satellite dish installer's attention to Article 810 and in particular Article 810-15 of the NEC, which covers proper installation and grounding of television receiving equipment, as well as to Article 820-40 of the NEC, which specifies that the satellite dish cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

## Owner's Record

The model and serial numbers are located on the back of the receiver. The number for the access card is on front of the card. Record these numbers in the space provided below. Refer to these numbers whenever you need to call your sales or service representative regarding this product.

Model Number: **SAT-B1**

Serial Number: \_\_\_\_\_

Access Card Number: \_\_\_\_\_

## Customer Support

### For DSS Programming

For subscription information, or to resolve problems related to DSS programming, call:

**DIRECTV® at 1-800-DIRECTV (347-3288) or  
USSB at 1-800-204-USSB (8772).**

### For DSS Hardware and Installation

To arrange for the installation of your DSS system, call the dealer from whom you purchased your system.

For general information, or to resolve problems related to the operation of your satellite receiver or antenna, please contact your Sony brand DSS dealer. If your dealer or installer is unable to answer your questions, call the Sony DSS Customer Support line at **1-800-838-SONY (7669)**.

### Trademark and Copyrights

Express Navigator is a trademark of Sony Corporation. DIRECTV and DSS are registered trademarks of DIRECTV, Inc., a unit of GM Hughes Electronics. USSB and USSB Entertainment Plus are official service marks of the United States Satellite Broadcasting Company, Inc. HBO is a registered trademark of Time Warner Entertainment Company, L.P. Showtime is a service mark of Showtime. MTV: Music Television is a registered trademark of MTV Networks, a division of Viacom International Inc. Comedy Central is a registered trademark of Comedy Partners.

### Macrovision Information

This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology is granted by Macrovision for home and other limited DSS IRD pay-per-view uses only. Reverse engineering or disassembly is prohibited.

### Note on Recording Programming

Programming may be taped for home viewing only. All other taping is expressly prohibited. Some programming may not be taped. An additional taping fee may be applied. Call your program providers for details.

# Contents

## **Chapter 1**

### **Introducing the DSS System**

- 5 DSS Features
- 6 Unpacking
- 7 Inserting Batteries into the Remote Control

## **Chapter 2**

### **Using Basic Functions**

- 10 Using the Master Guide
- 11 Using the Station Index

## **Chapter 3**

### **Connecting Your System**

- 13 Overview
- 14 TV Only
- 16 TV and VCR
- 18 Home Theater System  
(Hi-Fi TV, Hi-Fi VCR, Audio/Video Receiver)
- 20 Setting Up Your DSS System

## **Chapter 4**

### **Using the System Features**

- 21 Overview
- 22 Before You Get Started ...
- 23 Using the On-Screen Displays: Highlight and Select
- 24 Displaying the Master Guide
- 25 Features of the Master Guide
- 26 Moving Through the Master Guide
- 28 Selecting a Program from the Guide
- 29 Selecting Program Guides and Lists By Category
- 31 Selecting the Custom Guide
- 32 Selecting Other (Program Provider) Guides
- 33 Using the Station Index
- 35 Selecting the Favorite Station Guide
- 36 Using DISPLAY and JUMP
- 37 Selecting Alternate Audio
- 38 Canceling Purchases
- 39 Checking Your Purchase Record
- 40 Reading Your Messages
- 42 Selecting Data Services

## **Chapter 5**

## **Using the Custom Setup Menu**

- 45** Overview
- 46** Displaying the Custom Setup Menu
- 47** Setting Up a Favorite Station Guide
- 49** Setting a Default Language
- 50** Setting Locks and Limits
- 55** Setting Up a List of Custom Stations

## **Chapter 6**

## **Using the Installation Menu**

- 57** Overview
- 58** Displaying the Installation Menu
- 59** Setting Up the Satellite Antenna
- 60** Replacing Your Access Card
- 62** Setting the Aspect Ratio
- 63** Running a System Test

## **Appendix**

## **Other Information**

- 66** Location and Function of Controls
- 68** Using the Remote Control
- 70** Programming the Remote
- 72** Troubleshooting
- 74** Precautions
- 75** FCC Regulations and Information
- 76** Limited Warranty
- 77** Specifications
  
- 78** Index

# Introducing the DSS System

Welcome to the Sony brand DSS (Digital Satellite System), the ultimate digital entertainment experience. Read this chapter for an overview of the features of the system and to check the carton contents for the DSS receiver. This chapter also describes how to insert batteries into the remote control.

## DSS Features

---

Here are just a few benefits of the DSS system that you'll enjoy:

### Excellent Performance

- ☐ Superior, digital-quality video that rivals the performance of most laser-disc players.
- ☐ Crisp digital-quality audio that will enhance your TV or home theater experience.

### Premium Entertainment

- ☐ Choose from a variety of program packages available through your program providers, DIRECTV® and USSB<sup>SM</sup>.

### Convenience and Ease-of-Use

- ☐ Order premium pay-per-view movies with the remote control. Pay-per-view programs start as often as every 30 minutes, so you can watch programs when *you* want to see them. To watch a program, just use the remote to select it directly from the Master Guide.
- ☐ Sony's Express Navigator™ on-screen display system guides you through all the system features and functions.
- ☐ Select from a variety of program guides that are sorted by program categories, including Sports, Movies, News, and more.


### Customizable

- ☐ Create a Custom Program Guide and up to three of your own Favorite Station Guides for stations you watch most often.
- ☐ Set up a passcode, which lets you set up spending limits and control viewing of programs by rating and station.
- ☐ Compatible with both 4:3 (standard) or 16:9 (widescreen) TVs.
- ☐ An additional data port on the receiver accommodates new technologies, such as high-definition television, as they are introduced in the future.

# Unpacking


---

Check to make sure you've received the following items in the DSS receiver's carton:




**DSS Receiver  
with Access Card \***


**AC Power Cable**



**Audio/Video Cable (1)**



**Remote  
Commander**



**Phone Line**



**RF Coaxial Cable**



**Size AA Batteries**

\* The access card comes already inserted into the DSS receiver.

If you are missing items, contact the dealer from whom you purchased the DSS receiver.

**Note**

*Keep the original carton and packing materials to safely transport the system in the future.*


# Inserting Batteries into the Remote Control

---

Before you can use the remote control, you must first insert the supplied batteries. If you want to use this remote control to operate your TV or cable box, you must also program the remote, as described in the Appendix on page 70.

To install the batteries:

- 1 Push and slide open the battery compartment.




- 2 Insert two size AA batteries (supplied). Be sure to line up the + and - on the batteries with the + and - on the battery compartment.

## Notes on Batteries

- ☐ Under normal conditions, batteries will last up to six months. If the remote control does not operate properly, the batteries might be worn out. When replacing batteries, replace both of them with new ones, and do not mix different types of batteries together.
- ☐ When you remove the batteries — to replace them, for example — any codes you've set may be erased. If this happens, you must reprogram the remote. See "Programming the Remote" on page 70 for details.

# Using Basic Functions

You can start watching programs using just a few buttons on the remote control. Here's an overview of the buttons you'll use most often.



### DSS POWER Button

Turns the DSS receiver on and off.

### GUIDE Button

Brings up the Master Guide.

### Arrow Buttons

Scrolls through the Master Guide.

### ✦ Button

Selects the program that's highlighted. When a program guide is not displayed, pressing the ✦ button brings up the Station Index.

### CH/PAGE Buttons

Changes the channel. When a program guide is displayed, pressing the CH/PAGE buttons pages through the guide.

The following pages describe a quick start to using the Master Guide and the Station Index.

Chapter 4 contains procedures for using all the system features.





# Using the Master Guide

The Master Guide is the main program guide. It contains all the programming that's available from your program providers, including the programming to which you subscribe.

- 1 Press the GUIDE button to bring up the Master Guide.


*Your Master Guide may not look exactly like this. The stations displayed depend on the program provider(s) you select.*

MASTER GUIDE				WED OCT 5 8:45 PM
 PRESS  FOR PURCHASE INFORMATION		<b>Four Weddings and a Funeral</b> Hugh Grant, Andie McDowell. A confirmed bachelor meets the woman of his dreams at a friend's wedding and, for the first time, contemplates the idea of marriage for himself. (CC, S) (A, S, L)		
WED	▼ 8:00 PM	▼ 8:30 PM	▼ 9:00 PM	
SHO2987	Boxing	In the Line of Fire		
MTV 989	Music Videos		The Real World	
COM 990	Saturday Night Live		Monty Python...	
USSB 999	USSB Background			
DTV 100	Direct Ticket Previews			
DTV 102	Four Weddings and a Funeral			
DTV 105	Philadelphia		Like Water for ...	







- 2 Move the highlight to the name of the program you want.

You'll hear the audio and see the video (in the background) of each program as they are highlighted.

The table below lists the various ways in which you can move around in the guide.

- 3 Press the  button to select the highlighted program.


## Moving Around In the Master Guide


To Do This ...	Press This Button
Go to other stations in the guide one station at a time	 and  buttons
Go to other time slots in the guide one time slot at a time	 and  buttons
Go to other stations in the guide one "page" at a time	PAGE  (CH+) and PAGE  (CH-) buttons
Go to a station directly	0-9 buttons (to specify the station number)
Return to the last station you were watching	EXIT button


# Using the Station Index

You can use the Station Index to select a station by its station logo/call letters (such as CNN), rather than its current program's name.

## Note

Before you can bring up the Station Index, you must first clear the program guide from your TV screen. Pressing EXIT removes all on-screen displays. Also, you may need to change to another station if a message appears, which requests that you press the  button to purchase the program, etc.


- 1 Press the  button to bring up the Station Index.









- 2 Move the highlight to the station you want.

You'll hear the audio and see the video (in the background) of each program, as they are highlighted.

The table below lists the various ways in which you can move around in the Station Index.

- 3 Press the  button to tune to the program that's playing on the station you've highlighted.

## Moving Around In the Station Index

To Do This ...	Press This Button
Go to other stations in the guide, one station at a time	    buttons
Go to other stations in the guide, one "page" at a time	PAGE  (CH+) and PAGE  (CH-) buttons
Go to a station directly	0-9 buttons (to specify the station number)
Return to the last station you were watching	EXIT button

Your Station Index may not look exactly like this. The stations displayed depend on the program provider(s) you select.

# Connecting Your System

Read this chapter to set up your DSS receiver for the first time, or to add or remove audio or video components connected to your system.

## Overview

---

You can connect the DSS receiver in a variety of configurations. The answers to the following questions will determine how you hook up and operate your DSS receiver. For example:

- ☐ Do you have cable TV or a broadcast (terrestrial) TV antenna?
- ☐ What type of connectors do your TV and VCR have: S-VIDEO, A/V (RCA-type), or RF coaxial?
- ☐ Do you plan to integrate your DSS receiver with your audio or video system?

## General Recommendations

Detailed hookup instructions are provided on the pages that follow. For optimum audio and video performance, follow these general recommendations as much as possible when hooking up your components:

- ☐ If you have an audio or audio/video system, consider integrating the DSS receiver into a home theater configuration to take advantage of your hi-fi system's audio capabilities.
- ☐ If your TV has an S-VIDEO jack, use it to connect your TV to the DSS receiver. An S-Video connection provides a better picture than RCA-type video or RF connections.
- ☐ If your TV doesn't have an S-VIDEO jack, use your TV's A/V connectors to connect your components. An A/V connection provides a better picture and audio when compared to an RF connection.
- ☐ If you have other Sony components that include CONTROL-S jacks, you can connect these components via their CONTROL-S jacks in order to pass remote control signals between the DSS receiver and these components. This allows you to hide components behind cabinet doors.


# TV Only

## TV With RF Connector Only

*Some TVs label this jack RF IN, instead of UHF/VHF IN.*

Refer to the illustration below.

- 1 Connect the RG-6 cable from the satellite antenna's LNB to the DSS receiver's SATELLITE IN jack.
- 2 Connect the DSS receiver's VHF(SAT)/UHF OUT jack to the TV's UHF/VHF IN jack.
- 3 Connect one end of the telephone line cord to the DSS receiver's TEL LINE jack. Connect the other end to your home's modular telephone outlet.
- 4 Connect one end of the AC power cord to the DSS receiver's AC IN jack. Connect the plug end to an AC outlet.



### Optional Connections


- ☐ If you have a cable input, cable box, or a terrestrial TV antenna, connect it to the DSS receiver's UHF/VHF IN jack.
- ☐ To connect the DSS receiver to your audio system, use audio cables to connect the DSS receiver to your audio receiver's AUDIO IN jacks.

## TV With A/V Connectors

*If your TV has only one AUDIO IN jack, connect the lower (mono) AUDIO L jack on the DSS receiver to the TV's AUDIO IN jack.*

Refer to the illustration below.

- 1** Connect the RG-6 cable from the satellite antenna's LNB to the DSS receiver's SATELLITE IN jack.
- 2** Connect the DSS receiver's A/V jacks to the TV's A/V IN jacks.
- 3** Connect one end of the telephone line cord to the DSS receiver's TEL LINE jack. Connect the other end to your home's modular telephone outlet.
- 4** Connect one end of the AC power cord to the DSS receiver's AC IN jack. Connect the plug end to an AC outlet.



*Some TVs label this jack RF IN, instead of UHF/VHF IN.*

### Optional Connections

- ☐ If you have a cable input, cable box, or a terrestrial TV antenna, connect it to the TV's UHF/VHF IN jack.
- ☐ **Best Connection:** If your TV has an S-VIDEO jack, use an S-VIDEO cable to connect the DSS receiver's S-VIDEO jack to the TV's S-VIDEO IN jack. This provides the best picture quality. Then use audio cables to connect one set of the DSS receiver's audio jacks to the TV's AUDIO IN jacks.
- ☐ To connect the DSS receiver to your audio system, use audio cables to connect the DSS receiver to your audio receiver's AUDIO IN jacks.

# TV and VCR

Refer to the illustration on the opposite page.

- 1** Connect the RG-6 cable from the satellite antenna's LNB to the DSS receiver's SATELLITE IN jack.
- 2** Connect the DSS receiver's A/V jacks to the A/V IN jacks on the the TV and VCR. If your VCR has only one AUDIO IN jack (monoaural VCR), connect it to the lower (mono) AUDIO L jack on the DSS receiver.
- 3** Connect the DSS receiver's VHF(SAT)/UHF OUT jack to the VCR's UHF/VHF IN jack.
- 4** Complete one of the following to connect the VCR to the TV:
  - ☐ *Better Connection:* If both your TV and VCR have A/V jacks, connect the VCR's A/V OUT jacks to the TV's A/V IN jacks.
  - ☐ *Good Connection:* If your TV or VCR has only an RF jack, connect the VCR's UHF/VHF OUT jack to the TV's UHF/VHF IN jack.
- 5** Connect one end of the telephone line cord to the DSS receiver's TEL LINE jack. Connect the other end to your home's modular telephone outlet.
- 6** Connect one end of the AC power cord to the DSS receiver's AC IN jack. Connect the plug end to an AC outlet.


*Some VCRs and TVs label this jack RF IN, instead of UHF/VHF IN.*

## Optional Connections

- ☐ If you have a cable input, cable box, or a terrestrial TV antenna, connect it to the DSS receiver's UHF/VHF IN jack.
- ☐ *Best Connection:* If your TV has an S-VIDEO jack, use an S-VIDEO cable to connect the DSS receiver's S-VIDEO jack to the TV's S-VIDEO IN jack. This provides the best picture quality. Then use audio cables to connect one set of the DSS receiver's audio jacks to the TV's AUDIO IN jacks.
- ☐ To connect the DSS receiver to your audio system, use audio cables to connect the DSS receiver to your audio receiver's AUDIO IN jacks.

## Note

*When watching a program that is protected by Macrovision, turn the VCR off to ensure a quality picture.*



# Home Theater System

## (Hi-Fi TV, Hi-Fi VCR, Audio/Video Receiver)

---

Refer to the illustration on the opposite page.

- 1** Connect the RG-6 cable from the satellite antenna's LNB to the DSS receiver's SATELLITE IN jack.
- 2** Connect the DSS receiver's A/V jacks to the VCR and A/V receiver's A/V IN jacks.
- 3** Connect the VCR's A/V OUT jacks to one set of the A/V receiver's A/V IN jacks.
- 4** Connect the A/V receiver's MONITOR OUT jack to the TV's VIDEO IN jack.
- 5** Connect one end of the telephone line cord to the DSS receiver's TEL LINE jack. Connect the other end to your home's modular telephone outlet.
- 6** Connect one end of the AC power cord to the DSS receiver's AC IN jack. Connect the plug end to an AC outlet.

### Optional Connections


- ☐ If you have a cable input, cable box, or a terrestrial TV antenna, connect it to the VCR's UHF/VHF IN jack.
- ☐ *Best Connection:* If your TV has an S-VIDEO jack, use an S-VIDEO cable to connect the DSS receiver's S-VIDEO jack to the TV's S-VIDEO IN jack. This provides the best picture quality. Then use audio cables to connect one set of the DSS receiver's audio jacks to the A/V receiver's AUDIO IN jacks.

### Note

*In this configuration, the A/V receiver must be turned on in order to pass the video signals through to your TV. When watching a program that is protected by Macrovision, turn the VCR off to ensure a quality picture.*

*Some VCRs label this jack RF IN, instead of UHF/VHF IN.*





# Setting Up Your DSS System

---

## Viewing Satellite Programs

- 1 Turn on the TV, and then set the TV's line input to the DSS receiver. (For example, set the TV to channel 3 or 4, if you used an RF connection; or set to VIDEO1, etc., if you used an A/V connection.)
- 2 Turn on the VCR and A/V receiver, if you connected these components. Then set their output switches accordingly.
- 3 Turn on the DSS receiver and select a station.

## Viewing Cable or Off-Air Programs

### Note

*The following instructions apply only if you connected your cable TV or terrestrial antenna to your DSS receiver.*

- 1 Turn off your DSS receiver, or press the TV/DSS button to set the DSS receiver to TV mode (DSS indicator on the front panel is off).
- 2 Turn on the TV and then:
  - ☐ If you have a cable box, turn it on and then tune the TV to the output channel of your cable box, usually channel 3 or 4.
  - ☐ If you don't have a cable box, just tune your TV to the station you want to watch.

## Recording Satellite Programs While Watching Cable or Off-Air Programs

### Note

*The following instructions apply only if you connected your cable TV or terrestrial antenna to your DSS receiver.*

- 1 Turn on the TV and then:
  - ☐ If you have a cable box, turn it on and then tune the TV to the output channel of your cable box, usually channel 3 or 4.
  - ☐ If you don't have a cable box, tune your TV to the station you want to watch.
- 2 Turn on the DSS receiver, and tune to the program you want to record. Then set the VCR to line input, and start recording, according to your VCR's instruction manual.
- 3 Press the TV/DSS button to set the DSS receiver to TV (DSS indicator on the front panel is off).

The DSS receiver's signal is sent to the VCR, while the off-air signal is sent to your TV for you to watch.

### Note

*You cannot record one satellite program while watching another satellite program (unless you have a second DSS receiver). When watching a program that is protected by Macrovision, turn the VCR off to ensure a quality picture.*

# Using the System Features

Read this chapter to learn how to use system features including the Master program guide, Station Index, Favorite Station Guide, and the ordering of pay-per-view programs.

## Overview

---

This chapter provides detailed instructions for using most of the features of your DSS receiver. Topics include:

- ☐ Checking to make sure your system is completely set up and ready to be used (page 22).
- ☐ Using Highlight and Select, the simple, two-step process for operating all the on-screen displays (page 23).
- ☐ Displaying and navigating through the Master Guide (page 24).
- ☐ Selecting subscription and pay-per-view programs from the program guides (page 28).
- ☐ Choosing from the two program guide formats, Guide and List, and selecting special program guides sorted by category and subcategory (page 29).
- ☐ Using the Custom Guide (page 31).
- ☐ Using the three Favorite Station Guides (page 32).
- ☐ Using the Station Index (page 36).
- ☐ Displaying the Program Banner and using the JUMP feature (page 36).
- ☐ Selecting an alternate audio track for the program you're currently watching (page 37).
- ☐ Canceling pay-per-view programs you've ordered (page 38).
- ☐ Checking your pay-per-view purchase record (page 39).
- ☐ Reading mail messages sent to your DSS receiver (page 40).
- ☐ Selecting a data service (page 42).

## Before You Get Started ...

---

Make sure you (or your DSS system installer) have completed the following procedures before you start using your DSS receiver:

- 1** Install the satellite antenna, as described in the *Satellite Antenna Installation Manual*.

### **Note**

*Make certain that you (or your DSS system installer) have optimized the signal strength. If the signal is not optimized, you may experience losses in audio or video, especially during rain, snow, or other conditions that tend to degrade signal performance. See the Satellite Antenna Installation Manual for details on pointing the dish and optimizing the antenna's signal strength.*

- 2** Connect the satellite antenna to your DSS receiver. Then connect the receiver to your television and telephone line. (See Chapter 3.)

### **Note**

*Your phone line must be connected to the DSS receiver in order for you to purchase a pay-per-view program with the DSS remote control.*

- 3** Make sure the access card is inserted into the DSS receiver. The receiver comes with the card already inserted. (See page 60 for details on inserting the access card.)
- 4** Call your program providers (DIRECTV and USSB) to activate your service. You'll need to provide information, including the model and serial numbers of your DSS receiver and the access card number.

## If Your System Is Not Completely Installed ...

See the manual that came with the satellite antenna and Chapter 3 of this manual for complete installation instructions. Or, see your DSS dealer to arrange for a professional installation or the purchase of the Sony-brand DSS Installation Kit.

# Using the On-Screen Displays: Highlight and Select

All of the features and functions of the DSS receiver can be operated using a simple, two-step process: Highlight and Select. These two steps are explained below.

## Step 1: Highlight

- ❑ To highlight, press the arrow buttons on the remote to move the on-screen **highlight** to the item that you want to select.

## Step 2: Select

- ❑ After you've highlighted the item that you want, select it by pressing the **+** button.

## Example: Highlight and Select

- 1 In the sample menu that follows, pressing the **↑** button moves the highlight from ITEM 5...

SAMPLE MENU		
ITEM 1	ITEM 2	ITEM 3
ITEM 4	ITEM 5	ITEM 6
ITEM 7	ITEM 8	ITEM 9

... to ITEM 2.

SAMPLE MENU		
ITEM 1	ITEM 2	ITEM 3
ITEM 4	ITEM 5	ITEM 6
ITEM 7	ITEM 8	ITEM 9

- 2 Pressing the **+** button selects ITEM 2.

You can apply this basic operation of highlighting and selecting to perform any of the system's functions.

## Displaying the Master Guide

---

You can select programs using the CH+ and CH- buttons, or you can enter the station number directly using the 0-9 buttons. However, because DSS offers you such a variety of programming choices, you'll get the most out of the system by using one of the on-screen program guides to find the programs you want to watch.

The Master Guide, the main program guide, lists all the programs being offered by your program providers, including regular programs and pay-per-view events.

### To display the Master Guide:


- ☐ Press the GUIDE button on the remote


OR

- ☐ Press the MENU button to bring up the Main Menu. To display the Master Guide, highlight and then select MASTER GUIDE from the menu.

#### Tip

You can select menu items directly by pressing the corresponding number button. For example, press 2 to select the Master Guide.

The  symbol indicates that this selection has a submenu that contains additional selections.

MAIN MENU		
SELECT GUIDE 1	MASTER GUIDE 2	SELECT LIST 3
MOVIES GUIDE 4	EXIT 5	MOVIES LIST 6
OTHER GUIDES 7	CUSTOM GUIDE 8	SYSTEM MENU  9

The Master Guide is discussed in more detail on the following pages.

# Features of the Master Guide

When you select the Master Guide from the Main Menu or press the GUIDE button on the remote, the Master Guide appears:

The screenshot shows the Master Guide interface. At the top, the title 'MASTER GUIDE' is on the left, and the date and time 'WED OCT 5 8:45 PM' are on the right. Below the title is a station logo and a program description for 'Four Weddings and a Funeral'. A 'PRESS + FOR PURCHASE INFORMATION' button is also visible. The main part of the screen is a schedule grid with columns for different times of the day (8:00 PM, 8:30 PM, 9:00 PM) and rows for different stations (SHO2987, MTV 989, COM 990, USSB 999, DTV 100, DTV 102, DTV 105). A page indicator is shown on the right side of the grid.

Labels pointing to the interface elements:

- Program Guide Title: MASTER GUIDE
- Station Logo: [Logo]
- Day, Date, Time: WED OCT 5 8:45 PM
- Program Description: Four Weddings and a Funeral. Hugh Grant, Andie McDowell. A confirmed bachelor meets the woman of his dreams at a friend's wedding and, for the first time, contemplates the idea of marriage for himself. (CC, S) (A,S, L)
- Schedule Grid: [Grid containing station names, numbers, and program titles]
- Page Indicator: [Indicator showing current page position]

Program guides, such as the Master Guide shown above, feature a variety of elements, including:

- ☐ Program guide title, such as Master Guide, Movie Guide, Sports Guide, etc.
- ☐ Current day of the week, date and time.
- ☐ Station logo (when available) and program description of the currently highlighted station.
- ☐ Schedule grid, which includes:
  - ☐ Station names, numbers, and program titles. These appear in ascending numerical order from top to bottom.
  - ☐ Time slots. These appear left to right, with the current time's programming in the leftmost position.
  - ☐ Page indicator. This shows you approximately which page you're on, relative to all the pages in the guide. The size of the indicator is proportional to the overall size of the entire program guide.

# Moving Through the Master Guide

---

The on-screen program guides are displayed only one page at a time. Because the program guide usually contains many pages, you need to move through the guide to see more of the programs contained in the guide. You can move by scrolling, paging, and direct station tuning.

## Scrolling

To scroll, use the arrow buttons to move the highlight one position at time. You can scroll to different stations or time slots.

**To move to other stations in the guide one station at a time:**

- ☐ Press the **↑** and **↓** buttons.

**To move to other time slots in the guide:**

- ☐ Press the **←** and **→** buttons.

## Paging Vertically Through the Stations

To page, use the PAGE buttons to move through the guide a page at a time. This allows you to move through the guide more quickly than scrolling.

**To page through the guide:**

- ☐ Press the PAGE **↑** and PAGE **↓** buttons.

The PAGE **↑** button pages in the up direction. The PAGE **↓** button pages in the down direction.

## Paging Through Later Program Start Times

**To display future time slots in the guide:**

- ☐ Press the GUIDE button.

Pressing the GUIDE button repeatedly cycles through all the available time slots in the guide as they are made available by your program providers (for example, +6 hrs., +18 hrs., +32 hrs., +46 hrs., +60 hrs.).

### **Note**

*To select a future program guide directly, press the MENU button and then select OTHER GUIDES. See page 32 for details.*

## Direct Station Tuning

**To move to a station directly:**

- ☐ Press the 0-9 buttons to specify the station number. Press the ENTER button to change the station more quickly.



## Displaying Favorite Stations

To see your favorite stations in the program guide:

- ☐ Press the FAVORITE button.


Pressing the FAVORITE button repeatedly cycles through the stations currently set for the three Favorite Station Guides (FAV A, B, and C), and then back to the normal guide.

### **Note**

*See page 47 for instructions on setting up your favorite stations.*

## Exiting the Guide

There are two ways to exit the program guide:

- ☐ Select a program from the guide by pressing the  button. (See "Selecting a Program from the Guide" on page 28 for details.)

OR

- ☐ Press the EXIT button on the remote. You will be returned to the last program you were watching before the Master Guide was displayed.

## Selecting a Program from the Guide

For all programs except pay-per-view (PPV), you can select a program from the guide just by pressing the **+** button. If the program is currently showing, the guide disappears and the program you selected appears. If the program hasn't started yet, the guide remains on screen, and displays information about that program.

Watching a PPV program is similar, except it requires you to order the program before you can watch it beyond the free preview period (usually about five minutes after the program starts).

### Note

Your phone line must be connected to the DSS receiver in order for you to purchase a pay-per-view program with the DSS remote control.

## Ordering Pay-Per-View Programs

Selecting **RETURN** returns you to the previous screen, without purchasing the program.

Selecting **TIMES** brings up a list of additional show times that you can choose from for the program you selected.

A **PREVIEW** button, which gives you a free preview of the program, appears only when the preview is available.

Selecting **NO** returns you to the previous screen, without purchasing the program.

### To order a PPV program listed in the program guide:

- 1 Highlight the program name in the guide and press the **+** button.
- 2 Select **BUY** from the Purchase Program screen.

PURCHASE PROGRAM		
Title:	Four Weddings and a Funeral	<b>RETURN</b> <b>BUY</b> <b>TIMES</b> <b>HELP</b>
Description:	Hugh Grant, Andie McDowell. A confirmed bachelor meets the woman of his dreams at a friend's wedding and, for the first time, contemplates the idea of marriage for himself. (CC, S) (A,S, L)	
Channel:	102	
Time:	Wed Oct 5 8:00PM - 9:30PM	
Rating:	R	
Price:	\$2.99	

- 3 When the Confirm Purchase screen appears, select **YES** to confirm your purchase.

CONFIRM PURCHASE		
Do you want to purchase this program?		<b>YES</b> <b>NO</b>
Title:	Four Weddings and a Funeral	
Total Cost:	\$2.99	
Channel:	102	
Time:	Wed Oct 5 8:00PM - 9:30PM	

To watch the program, just tune to the station when the program is about to start. Your program providers will bill you automatically.

## About Copy-Protection


Some PPV programs are copy-protected by Macrovision at the discretion of the copyright owner. When watching a PPV program, turn the VCR off to ensure a quality picture.

# Selecting Program Guides and Lists By Category



In addition to using the Master Guide, you can use the SELECT GUIDE and SELECT LIST options in the Main Menu to select subsets of the Master Guide. These subsets are sorted by program categories, such as Movies, Sports, News, and so on. You can also choose from two program guide formats: Guide and List.

- ☐ The Guide format lists stations in ascending numerical order (such as the Master Guide).
- ☐ The List format lists programs in alphabetical order by program title, as shown below.

The buttons that appear for each program indicate start times.

To select a program, highlight the start time button and then press the  button.

For example, in this sample Movie List, "Four Weddings and a Funeral," with a start time of 9:00PM, is highlighted.

MOVIES LIST		WED OCT 5 8:45 PM					
 PRESS  FOR PURCHASE INFORMATION		<b>Four Weddings and a Funeral</b> Hugh Grant, Andie McDowell. A confirmed bachelor meets the woman of his dreams at a friend's wedding and, for the first time, contemplates the idea of marriage for himself. (CC, S) (A, S, L)					
		WED 8 PM	8:30	9 PM	9:30	10 PM	10:30
Ace Ventura: Pet Detective	<						
Bram Stoker's Dracula							
Dennis the Menace							
Four Weddings and a Funeral	<						
Like Water for Chocolate							
Philadelphia	<						
The Natural							


## How SELECT GUIDE and SELECT LIST Change the Main Menu

The selections you make using SELECT GUIDE and SELECT LIST affect the program categories displayed in the Main Menu. The category you select using SELECT GUIDE changes button 4 of the Main Menu. The category you select using SELECT LIST changes button 6 of the Main Menu.

This feature allows you to recall the last program guide or list that you selected.

Example: If you select the Sports Guide using SELECT GUIDE, button 4 of the Main Menu automatically changes to SPORTS GUIDE.

Similarly, button 6 of the Main Menu automatically updates to the last selection you made using SELECT LIST.

MAIN MENU		
SELECT GUIDE 1	MASTER GUIDE 2	SELECT LIST 3
SPORTS GUIDE 4	EXIT 5	NEWS LIST 6
OTHER GUIDES 7	CUSTOM GUIDE 8	SYSTEM MENU  9

### Note

Guides displayed using buttons 4 and 6 show ALL subcategories of the program category that you selected, regardless of your subcategory selections.

Selecting a Program Guide or List By Program Category

Selecting CANCEL returns you to the previous screen, without saving your selections.

To select another guide or program guide format:

- 1 Press the MENU button to bring up the Main Menu.
- 2 Select SELECT GUIDE or SELECT LIST from the Main Menu. The Select Category screen appears.

Select a program category, such as MOVIES. A selected category appears with a checkmark (✓) beside it. Then select OK.

SELECT GUIDE CATEGORY			
MOVIES ✓	SPORTS	SPECIALS	SERIES
NEWS	SHOPPING		
<div>OK CANCEL HELP</div>			

- 3 If the category you select has subcategories, the Select Subcategory screen appears.

Select the program subcategories you want (you can select more than one subcategory). A selected subcategory appears with a checkmark (✓) beside it. To deselect a subcategory, just select it again. The checkmark disappears. After you've made your selections, select OK.

SELECT MOVIES SUBCATEGORY			
ACTION/ADVENTURE ✓	CHILDREN ✓	COMEDY ✓	DRAMA ✓
FANTASY ✓	HORROR ✓	MUSICAL ✓	ROMANCE ✓
SCIENCE FICTION ✓	WESTERN ✓	OTHER ✓	
<div>OK CANCEL ALL NONE HELP</div>			

Selecting ALL places a checkmark beside all the subcategories. Selecting NONE removes the checkmark from all the subcategories.

Selecting CANCEL returns you to the previous screen, without saving your selections.

The program guide or list, which includes only stations that include programs in the category and subcategories you selected, appears.

The next time you display the Main Menu, it will include the Guide or List category that you selected. To change category selections, select SELECT GUIDE or SELECT LIST from the Main Menu.

## Selecting the Custom Guide

---


The Custom Guide is a program guide that you can create to include only the stations you want.

**Note**

See "Setting Up a List of Custom Stations" on page 55 for instructions on setting up your custom stations.

**To select the Custom Guide:**

- 1** Press the MENU button to bring up the Main Menu.
- 2** Select CUSTOM GUIDE from the Main Menu..

MAIN MENU		
SELECT GUIDE 1	MASTER GUIDE 2	SELECT LIST 3
SPORTS GUIDE 4	EXIT 5	NEWS LIST 6
OTHER GUIDES 7	CUSTOM GUIDE 8	SYSTEM MENU  9

The Custom Guide appears, which includes only stations that you specified when you set up your list of custom stations.

## Selecting Other (Program Provider) Guides

The Other Guides option includes alternative program guides, which are made available by your program providers, DIRECTV and USSB. These guides may contain groups of stations with similar subjects, for example, special promotions or pay-per-view programs. OTHER GUIDES also includes buttons for going directly to future time slots in the program guide.

### To select one of these other guides:

- 1 Press the MENU button to bring up the Main Menu.
- 2 Select OTHER GUIDES from the Main Menu. The Select Other Guide screen appears.

Select a program category. A selected program provider guide appears with a checkmark (✓) beside it. Then select OK to display the category and subcategory selection screens.

*This list of program guides may change, as guides are added or changed by your program providers.*

*Selecting CANCEL returns you to the previous screen, without saving your selections.*

SELECT OTHER GUIDE				
SUBSCRPTN ✓	PPV	PROMO	MULTIPLEX	OK
				CANCEL
+ 6 HRS	+ 19 HRS	+ 32.0 HRS	+ 45.0 HRS	HELP
+ 58.0 HRS	+ 71.0 HRS	ATTRACTIONS		


- 3 Select a program category and subcategory, as described on page 29.

The program provider guide, which includes only stations that include programs in the category and subcategories you selected, appears.


## Using the Station Index

The Station Index is an on-screen display that contains the station logo (or call letters) of all the stations in the system. You'll find the Station Index useful when you want to tune to a specific station, rather than to a specific program.

### Note






















Before you can bring up the Station Index, you must first clear the program guide from your TV screen. Pressing EXIT turns off the on-screen displays. Also, you may need to change to another station if a message appears, which requests that you press the  button to purchase the program, etc.

### To display the Station Index:

- ☐ Press the  button.







The Station Index appears. The station you are currently tuned to is automatically highlighted.

*Your Station Index may not look exactly like this. The stations displayed depend on the programming you've ordered.*

STATION INDEX						
 206	 207	 208	 209	 211	 212	 215
 216	 220	 222	 224	 225	 226	 227
 229	 230	 232	 233	 235	 236	 240

### Moving Through the Station Index

### To move through the Station Index:

- ☐ Press the     buttons to move one station at a time.
- ☐ Press the PAGE  and PAGE  buttons to page (move up or down two rows at a time).
- ☐ Enter the station number, using the 0-9 buttons.

## Displaying Favorite Stations in the Station Index








The top row contains your seven favorite stations from FAV A, FAV B, or FAV C.

The other rows represent all the other stations in the system.

### To display your favorite stations on the top row of the Station Index:

- ❑ Press the FAVORITE button.

Pressing the FAVORITE button repeatedly cycles through the three Favorite Station Guides (FAV A, B, and C).


STATION INDEX							FAV A
 240	MTV 989	TNT 212	HBO 980	 198	AE 256	TBS 233	
MUCH 216	 220	DIS1 222	DIS2 224	 225	DIS 226	 227	
USA 229	TRIO 230	TBS 232	 233	OTNN 235	CMN 236	 240	

### Note

See page 47 for instructions on setting up your favorite stations.

## Selecting a Program from the Station Index

### To select a program:

- ❑ Press the  button to tune to the highlighted station. The Station Index disappears.

### To exit the Station Index without changing stations:

- ❑ Press the EXIT button. The Station Index disappears, and you return to the station you were watching before displaying the Station Index.



## Selecting the Favorite Station Guide

The Favorite Station Guide is a program guide that you can create to include up to seven of your favorite stations. You can create up to three Favorite Station Guides, identified as FAV A, FAV B, and FAV C.

### Note

See page 47 for instructions on setting up your favorite stations.

### To bring up the Favorite Station Guide:

- ☐ Press the FAVORITE button.

### Note

Before you can bring up the Favorite Station Guide, you must first clear the program guide from your TV screen. Pressing EXIT turns off the on-screen displays.

FAVORITE STATION GUIDE				FAV A
240 NIGHT GALLERY	989 MTV MUSIC VIDEOS	212 TNT SHOGUN	980 HBO THE NATURAL	
198 PHILADELPHIA	256 AE BIOGRAPHY	233 TBS TOM AND JERRY	967 EXIT TO CURRENT STATION	

## Moving Through the Favorite Station Guide


### To move through the Favorite Station Guide:

- ☐ Press the arrow buttons to move one station at a time
- OR
- ☐ Enter the station number, by using the 0-9 buttons and pressing the ENTER button.

### To cycle through the three Favorite Station Guides (FAV A, FAV B, and FAV C):

- ☐ Press the FAVORITE button repeatedly.

### To select a program:

- ☐ Press the  button to tune to the highlighted station. The Favorite Station Guide disappears.

### To exit the Favorite Station Guide without changing stations:

- ☐ Select "Exit to Current Station," which appears in the bottom right corner of the Favorite Station Guide (or press the EXIT button).

## Using DISPLAY and JUMP

---


You can use the DISPLAY feature while you're watching programs. The JUMP features works while you're watching programs and while you're in any of the program guides.





### Displaying the Program Banner

The program banner provides useful information about the program you're currently watching.

#### To display the Program Banner:

- ☐ Press the DISPLAY button.



The Program Banner shows the program title, station name and number, start and end times, current date and time, and rating. It may also indicate that data services () and alternate audio tracks () are available, that new mail has been received () , and whether or not the system is locked ().

To turn off the Program Banner, press the DISPLAY button again.

For information about selecting data services, see page 42; alternate audio tracks, see page 37; mail messages, see page 40; system lock, see page 50.

### Jumping Back and Forth Between Stations

You can use the JUMP button to switch or "jump" back and forth between two stations.

#### To display the last station you selected:

- ☐ Press the JUMP button.

#### Note

*You cannot jump to stations you tuned to using the CH+/CH- buttons.*

## Selecting Alternate Audio

Your program providers may broadcast multiple audio tracks with a single video source. For example, a football game might use a different audio track for each sports commentator or a movie might include include both English and Spanish language audio tracks.

### How to Determine if Alternate Audio Tracks Are Available for a Program

To determine if an alternate audio track is available:

- 1 Tune to the program.
- 2 Press the DISPLAY button to bring up the Program Banner.

If the Program Banner includes the alternate audio symbol (🔊), this indicates that alternate audio tracks are available for that program.

### Selecting an Alternate Audio Track

To select an alternate audio track:

- 1 Press the MENU button to bring up the Main Menu.
- 2 Select SYSTEM MENU to bring up the System Menu.
- 3 Select ALTERNATE AUDIO.

SYSTEM MENU		
ALTERNATE AUDIO 1	CUSTOM SETUP MENU 2	CANCEL PURCHASE 3
MESSAGES 4	EXIT 5	REVIEW PURCHASES 6
	INSTALLATION MENU 8	MAIN MENU 9

- 4 The Alternate Audio screen appears, which lists only the audio tracks available for the program you are currently tuned to.

Select an audio track. Then select OK to return to the System Menu.

ALTERNATE AUDIO	
ENGLISH	SPANISH ✓
OK	
CANCEL	
HELP	

- 5 Select EXIT from the System Menu to return to the program you were watching.

The alternate audio track you select is available only while the current program airs. To change the default language for the audio of all programs, see "Setting a Default Language" on page 49.

*Selecting CANCEL returns you to the previous screen, without saving your selections.*

# Canceling Purchases

Use the Cancel Purchase screen if you order a pay-per-view program, and then decide you'd like to cancel the order before the program begins.

## Note

The Cancel Purchase screen lists only purchases made using the DSS receiver's remote control. It doesn't include purchases made by calling your program provider.

- 1 Press the MENU button to bring up the Main Menu.
- 2 Select SYSTEM MENU to bring up the System Menu.
- 3 Select CANCEL PURCHASE.

Once you tune to a purchased program, you cannot cancel its purchase.

SYSTEM MENU		
ALTERNATE AUDIO 1	CUSTOM SETUP MENU 2	CANCEL PURCHASE 3
MESSAGES 4	EXIT 5	REVIEW PURCHASES 6
	INSTALLATION MENU 8	MAIN MENU 9

- 4 Select the program you want to cancel. You can cancel only one program at a time. The selected program appears with a checkmark (✓) beside it. Then select CANCEL PPV.

Selecting RETURN returns you to the previous screen, without canceling the program's purchase.

CANCEL PURCHASE				
<input checked="" type="checkbox"/>	OCT 5	8:00PM	CH102 Four Weddings...	<div>RETURN</div> <div>CANCEL PPV</div> <div>HELP</div>
<input type="checkbox"/>	OCT 6	8:30PM	CH123 Major League II	
<input type="checkbox"/>	OCT 6	11:15PM	CH150 Speed	
<input type="checkbox"/>				

- 5 The Confirm Cancel Purchase screen appears. Select YES to confirm your cancellation and return to the System Menu.

Selecting NO returns you to the previous screen, without canceling the program's purchase.

CONFIRM CANCEL PURCHASE	
Do you want to cancel this purchase?	
Title:	Four Weddings and a Funeral
Total Cost:	\$2.99
Channel:	102
Time:	Wed Oct 5 8:00PM - 9:30PM
<div>YES</div> <div>NO</div>	

- 6 Select EXIT from the System Menu to return to the program you were watching.

# Checking Your Purchase Record




Use the Review Purchases screen to see a record of recent purchases you've made through your DSS receiver.

## Note

The Review Purchases screen lists only purchases made using the DSS receiver's remote control. It doesn't include purchases made by calling your program provider.



## To check the purchase record:







- 1 Press the MENU button to bring up the Main Menu.
- 2 Select SYSTEM MENU to bring up the System Menu.
- 3 Select REVIEW PURCHASES.

SYSTEM MENU		
ALTERNATE AUDIO 1	CUSTOM SETUP MENU  2	CANCEL PURCHASE 3
MESSAGES 4	EXIT 5	REVIEW PURCHASES 6
	INSTALLATION MENU  8	MAIN MENU  9

The Review Purchases screen appears, which lists the programs purchased and canceled.

- 4 After you've reviewed your purchases, select RETURN to return to the System Menu. Or, for more details, select the program name and then select REVIEW.

To review more than one page of purchases, press the PAGE  and PAGE  buttons to page through the displays.

REVIEW PURCHASES				
	OCT 5	Four Weddings and a Funeral	\$2.99	<div>RETURN</div> <div>REVIEW</div> <div>HELP</div>
	OCT 6	Major League II	\$2.99	
	OCT 6	Speed	Cancelled	
				
				
				

# Reading Your Messages

Occasionally, your program providers will send messages to your DSS receiver. These messages contain useful information about your system, such as information about new services, program promotions, or billing.

## How to Determine When You've Received Mail


There are several ways to tell if you have unread mail:

- ☐ The DSS receiver's front panel MESSAGE indicator is lit.
- ☐ An envelope (✉) appears in the Program Banner, accessed by pressing the DISPLAY button.
- ☐ An envelope (✉) appears in menu item 9 (System Menu) of the Main Menu.





## Displaying Your Messages

To display your messages:

- 1 Press the MENU button to bring up the Main Menu.
- 2 Select SYSTEM MENU.

MAIN MENU		
SELECT GUIDE 1	MASTER GUIDE 2	SELECT LIST 3
MOVIE GUIDE 4	EXIT 5	MOVIE LIST 6
OTHER GUIDES 7	CUSTOM GUIDE 8	SYSTEM MENU  9

- 3 Select MESSAGES.

SYSTEM MENU		
ALTERNATE AUDIO 1	CUSTOM SETUP MENU  2	CANCEL PURCHASE 3
MESSAGES  4	EXIT 5	REVIEW PURCHASES 6
	INSTALLATION MENU  8	MAIN MENU  9

The message's date, along with the first few words of the message, appear.

## Reading a Message

### To read a message:

- 1 Select the envelope from the Messages screen. A selected message appears with a checkmark (✓) beside it. Then select READ.

MESSAGES		
	11/6 Sign up now for our special ...	<b>READ</b>
	11/8 Welcome to USSB ....	<b>RETURN</b>
	11/23 Happy Thanksgiving ....	<b>HELP</b>

The full text of the message appears.

READ MESSAGE		
	11/23  Happy Thanksgiving from everyone at DIRECTV.	<b>RETURN</b> <b>ERASE</b> <b>HELP</b>

- 2 To erase a message after you've read it, select ERASE. To keep a message after you've read it, select RETURN.

#### Note

*Your mailbox can hold about 50 messages before exhausting the receiver's memory. To prevent accidental erasure, get in the habit of deleting your messages after you read them.*

- 3 Select EXIT from the System Menu to return to the program you were watching.

# Selecting Data Services

In the future, your program providers may make available data services, which you can access through specific stations using the DSS receiver's high-speed data port. For details about using the high-speed data port to access these data services, call your program providers.

## How to Determine if Data Services Are Available on a Station

To determine if data services are available on a specific station:

- 1 Tune to the station.
- 2 Press the DISPLAY button to bring up the Program Banner.

If the Program Banner includes the data services symbol (D), this indicates that data services are available for that specific station.

## Selecting a Data Service

*DATA SERVICES appears only when the station you're tuned to includes data services.*

To select a data service:

- 1 Press the MENU button to bring up the Main Menu.
- 2 Select SYSTEM MENU to bring up the System Menu.
- 3 Select DATA SERVICES.

SYSTEM MENU		
ALTERNATE AUDIO 1	CUSTOM SETUP MENU 2	CANCEL PURCHASE 3
MESSAGES 4	EXIT 5	REVIEW PURCHASES 6
DATA SERVICES 7	INSTALLATION MENU 8	MAIN MENU 9

- 4 The Data Services screen appears, which lists only the data services that are available for the station you are currently tuned to.

*Selecting CANCEL returns you to the previous screen, without saving your selections.*

DATA SERVICES				
DATA 1 ✓	DATA 2	DATA 3	DATA 4	OK
				CANCEL
DATA 5	DATA 6	DATA 7	DATA 8	DEFAULT
				BAUD RATE
				HELP



## 5 Select one of the following:

To Do This ...	Do This ...
Change the data service for the current station only	Select the data service and then select OK.
Change the data service for all stations	Select DEFAULT (then see "Changing the Default Data Service" below).
Change the baud rate for the DSS receiver's high-speed data port	Select BAUD RATE (then see "Setting the Baud Rate" below).

Call your program provider if you have questions about selecting a data service.

### Changing the Default Data Service

Selecting CANCEL returns you to the previous screen, without saving your selections.

#### To change the data service for all stations:

- 1 Select DEFAULT from the Data Services screen.
- 2 Select a default data service and then select OK.

DEFAULT DATA SERVICE				
DATA 1	DATA 2	DATA 3	DATA 4	OK CANCEL HELP
DATA 5	DATA 6	DATA 7	DATA 8	

Call your program provider if you have questions about default data services.

### Setting the Baud Rate

Selecting CANCEL returns you to the previous screen, without saving your selections.

#### To set the baud rate for the DSS receiver's high-speed data port:

- 1 Select BAUD RATE from the Data Services screen.
- 2 Select a baud rate for the high-speed data port and then select OK.

SET BAUD RATE				
2400	4800	9600	19200	OK CANCEL HELP

Call your program provider if you have questions about setting the baud rate.

# Using the Custom Setup Menu

Read this chapter to get information about customizing your system to match your personal viewing habits.

## Overview

---

Your DSS receiver includes several features you can use to customize your system to meet your individual preferences. You can:

- ☐ Create up to three Favorite Station Guides, with each containing up to seven stations (page 46).
- ☐ Set a default language for the audio of programs broadcast in multiple languages (page 49).
- ☐ Set system locks and limits, which allow you to control program viewing by ratings, spending amount, and station (page 50).
- ☐ Specify custom stations. In the Set Custom Stations screen, you specify stations from the Master Guide you want to skip. After you've set skipped stations, they will not appear in the Custom Guide (available in the Main Menu). These stations are also skipped over in the Station Index, and when you use the CH+/CH- buttons to change channels (page 55).

# Displaying the Custom Setup Menu

To customize your system, first bring up the Custom Setup Menu, as follows:

**1** Press the MENU button to bring up the Main Menu.

**2** Select SYSTEM MENU.

MAIN MENU		
SELECT GUIDE 1	MASTER GUIDE 2	SELECT LIST 3
MOVIE GUIDE 4	EXIT 5	MOVIE LIST 6
OTHER GUIDES 7	CUSTOM GUIDE 8	SYSTEM MENU 9

**3** Select CUSTOM SETUP MENU.

SYSTEM MENU		
ALTERNATE AUDIO 1	CUSTOMSETUP MENU 2	CANCEL PURCHASE 3
MESSAGES 4	EXIT 5	REVIEW PURCHASES 6
	INSTALLATION MENU 8	MAIN MENU 9

The Custom Setup menu appears.

CUSTOM SETUP MENU		
	SET FAVORITE STATIONS 2	
SET DEFAULT LANGUAGE 4	EXIT 5	SET LOCKS AND LIMITS 6
	SET CUSTOM STATIONS 8	SYSTEM MENU 9

The following pages describe how to use the Custom Setup Menu to personalize your system.

# Setting Up a Favorite Station Guide

The Favorite Station Guide is a program guide that you create. You can create up to three Favorite Station Guides, with each guide containing up to seven of your favorite stations.

## To set up a Favorite Station Guide:

- 1 Select SET FAVORITE STATIONS from the Custom Setup Menu.
- 2 Select FAV A, FAV B, or FAV C from the Set Favorite Stations screen.

The Set Favorite Stations screen displays three rows of seven stations. Each row represents one of the three Favorite Station Guides, labeled FAV A, FAV B, and FAV C.

SET FAVORITE STATIONS

FAV A [ ] [ ] [ ] [ ] [ ] [ ] [ ] RETURN HELP

FAV B [ ] [ ] [ ] [ ] [ ] [ ] [ ]

FAV C [ ] [ ] [ ] [ ] [ ] [ ] [ ]

A setup screen for the guide that you selected appears.

The top row represents the stations that are currently set for the Favorite Station Guide you selected.

The bottom rows represent all the other stations in the system.

SET FAVORITE STATIONS: FAV A

[ ] [ ] [ ] [ ] [ ] [ ] [ ] OK CANCEL

CNN 202	CRT 203	HLN 204	DTV 205	ESPN 206	DTV 207	ESNa 208
DTV 209	DTV 210	DTV 211	TNT 212	DTV 213	DTV 214	E! 215
DTV 216	DTV 217	DTV 218	DTV 219	TCM 220	DTV 221	DIS1 222

CLEAR HELP

The system is shipped with no favorite stations set, so the first time you see this screen, the top row is blank.

- 3 To add or change a station, first highlight a button in the top row.
- 4 Do one of the following:
  - ❑ To select a station from the bottom rows of stations, press the button. The highlight automatically moves to the stations in the bottom rows. Then go to step 5.
  - ❑ To select a station directly, enter the station's number, using the 0-9 buttons. Then repeat steps 3 and 4 for each station you want to include in the Favorite Station Guide.

- 5 To replace a favorite station in the top row, select a station from one of the bottom rows of stations.

**Note**

Use the PAGE↑ and PAGE↓ buttons to quickly move through the lower rows of stations.

The new station you select automatically replaces the highlighted station in the top row, and the highlight automatically moves to the next favorite station button in the top row.

*You can select CLEAR to automatically clear all the stations from the top row. Selecting CANCEL returns you to the previous screen, without saving your selections.*

SET FAVORITE STATIONS: FAV A								
USA 229								OK
								CANCEL
CNN 202	CRT 203	HLN 204	DTV 205	ESPN 206	DTV 207	ESNa 208		CLEAR
DTV 209	DTV 210	DTV 211	TNT 212	DTV 213	DTV 214	E! 215		HELP
DTV 216	DTV 217	DTV 218	DTV 219	TCM 220	DTV 221	DIS1 222		

- 6 Repeat steps 4 and 5 for each station you want to include in the Favorite Station Guide.
- 7 Select OK when you're finished setting your favorite stations.
- 8 Select RETURN when you're finished. Or, repeat steps 2 through 7 to set up another Favorite Station Guide (FAV A, B, or C).

SET FAVORITE STATIONS								
FAV A	USA 229	HLN 204	VH-1 965	A&E 250	ESPN 208	HBO 980	CNN 202	RETURN
								HELP
FAV B								
FAV C								

See "Selecting the Custom Guide" on page 31 for instructions on displaying and using the Favorite Station Guides.

# Setting a Default Language

Use the Set Default Language screen to specify the language you want to hear for programs broadcast in multiple languages.

For example, if you set the default language to Spanish and a program is broadcast in both English and Spanish, you'll automatically hear the audio in Spanish.

## Note

*If the default language you select is not available for a program that you tune to, you will not hear the default language. Instead, you'll hear one of the languages available for that program (usually English).*

## To set a default language:


- 1 Select SET DEFAULT LANGUAGE from the Custom Setup Menu.
- 2 Select a language and then select OK.

Selecting CANCEL returns you to the previous screen, without saving your selections.

SET DEFAULT LANGUAGE				
ENGLISH	SPANISH	FRENCH	GERMAN	OK
				CANCEL
ITALIAN	JAPANESE	KOREAN	CHINESE	HELP

You return to the Custom Setup Menu, and the DSS receiver is set to play back the selected language, when that language is available.

## Note

*You can change the audio track for a program that uses multiple audio tracks (indicated by the  symbol in the Program Banner) without changing the default language. For details, see "Selecting Alternate Audio" on page 37.*

# Setting Locks and Limits

The Locks and Limits feature gives you control over the use of your system. You can restrict program viewing by cost, ratings, and station. You can also set a lock to prevent the ordering of pay-per-view programs.

## To display the Set Locks and Limits screen:

- 1 Select SET LOCKS AND LIMITS from the Custom Setup Menu.

The Set Locks and Limits screen appears, with the current settings shown next to each button.

- 2 Select a lock or limit from the screen (see the descriptions below).

*If your system is locked, the padlock symbol appears (🔒), and you must first unlock it before you can make any changes to the locks and limits settings. See "Unlocking Your System" on page 54 for details.*

SET LOCKS AND LIMITS		
SPENDING LIMIT	None	LOCK
RATINGS LIMIT	NC17	RETURN
STATION LOCKS	0 Station(s) Currently Locked	HELP
PPV LOCK	Pay-Per-View Unlocked	

### Note

*Your DSS receiver is shipped to you unlocked, with the default settings as described below.*

Spending Limit	Lets you set a maximum spending limit for a single pay-per-view program. When the system is locked, you cannot purchase a program that costs more than the amount set. <b>The default setting is \$10.00.</b>
Ratings Limit	Allows you to set a maximum ratings limit. When the system is locked, you cannot view programs rated higher than the rating set. <b>The default rating is R.</b>
Station Locks	Lets you prevent the viewing of stations that you lock. When the system is locked, programs that appear on locked stations cannot be viewed. <b>The default is no stations locked.</b>
PPV Lock	Allows you to prevent PPV purchases. When the system and the PPV option are locked, pay-per-view programs cannot be purchased. <b>The default setting is unlocked.</b>

### Note





*After you've set a lock or limit, you must lock the system before any locks or limits take effect. Locking the system is described on page 53.*




## Setting a Spending Limit

Selecting **NO LIMIT** allows you to purchase any pay-per-view program, no matter how much it costs.

Selecting **CANCEL** returns you to the previous screen, without saving your selections.

### To set a spending limit:

- 1 Select **SPENDING LIMIT** from the Set Locks and Limits screen.
- 2 Enter a spending limit. Use the 0-9 or  and  buttons to enter the numerical value. (If you use the arrow buttons to enter the value, use the  and  buttons to move to the previous or next position.)

SET SPENDING LIMIT	
\$    .00	<div>OK</div> <div>CANCEL</div> <div>NO LIMIT</div> <div>HELP</div>


- 3 Select **OK** to return to the Set Locks and Limits screen. Then set any other locks and limits, if necessary.
- 4 Lock your system, as described in "Locking Your System" on page 53.






## Setting a Ratings Limit

Selecting **ALL** allows viewing of all programs. Selecting **NONE** prevents the viewing of all programs.

Selecting **CANCEL** returns you to the previous screen, without saving your selections.

### To set a ratings limit:

- 1 Select **RATINGS LIMIT** from the Set Locks and Limits screen.
- 2 Select a rating, beyond which programs cannot be watched. Locked ratings appear with a key () beside them. For example, in the following screen, the ratings limit has been set to **PG**.

SET RATINGS LIMIT				
NR (NOT RATED)	G	PG	PG-13 	<div>OK</div> <div>CANCEL</div>
NC-CONTENT 	R 	NR-MATURE 	NR-MATURE 	<div>ALL</div> <div>NONE</div> <div>HELP</div>

- 3 Select **OK** to return to the Set Locks and Limits screen. Then set any other locks and limits, if necessary.
- 4 Lock your system, as described in "Locking Your System" on page 53.



## Setting Station Locks

To quickly unlock or lock all stations, select ALL (to lock all) or NONE (to unlock all). Selecting CANCEL returns you to the previous screen, without saving your selections.

### To set station locks:

- 1 Select STATION LOCKS from the Set Locks and Limits screen.
- 2 Select stations that you want to lock from viewing. A locked station appears with a key (🔑) beside it. For example, in the following screen, stations 203, 204, 206, and 209 have been locked.

To unlock a station, just select it again. The key (🔑) disappears.

SET STATION LOCKS						
CNN 202	CRT 203 🔑	HLN 204 🔑	DTV 205	ESPN 206 🔑	DTV 207	ESNa 208
DTV 209 🔑	DTV 210	DTV 211	TNT 212	DTV 213	DTV 214	EI 215
DTV 216	DTV 217	DTV 218	DTV 219	TCM 220	DTV 221	DIS1 222
DTV 223	DIS2 224	DISC 225	TLC 226	TOON 227	DTV 228	USA 229

### Note

You can use the PAGE↑ and PAGE↓ buttons to quickly move through the rows of stations. You can also use the 0-9 buttons to enter the station number directly.

- 3 Select OK to return to the Set Locks and Limits screen. Then set any other locks and limits, if necessary.
- 4 Lock your system, as described in "Locking Your System" on page 53.

## Setting the Pay-Per-View Lock

Selecting CANCEL returns you to the previous screen, without saving your selections.

### To set the pay-per-view lock:

- 1 Select PPV LOCK from the Set Locks and Limits screen.
- 2 Select LOCK to prevent PPV program purchases. Select UNLOCK to allow PPV program purchases.

SET PPV LOCK	
LOCK	UNLOCK ✓

- 3 Select OK to return to the Set Locks and Limits screen. Then set any other locks and limits, if necessary.
- 4 Lock your system, as described in "Locking Your System" on page 53.

### Note





You can also set a PPV lock by setting the spending limit to \$0.00. See "Setting a Spending Limit" on page 51 for details.

## Locking Your System

### To lock an unlocked system:





- 1 Select LOCK from the Set Locks and Limits screen.

SET LOCKS AND LIMITS		
SPENDING LIMIT	\$10.00	<b>LOCK</b>
RATINGS LIMIT	PG	RETURN
STATION LOCK	4 Stations Locked	HELP
PPV LOCK	Pay Per View Unlocked	

- 2 Enter a four-digit passcode number. Use the 0-9 or  and  buttons to enter the numerical value. (If you use the arrow buttons to enter the value, use the  and  buttons to move to the previous or next position.)

Each number you enter appears as an asterisk (\*), which keeps your passcode secret.


Selecting CANCEL returns you to the previous screen, without saving your selections.

SET PASSCODE	
   	OK
	CANCEL
	HELP

#### Note


**DON'T FORGET YOUR PASSCODE.** You'll need this number to unlock your system or to make any changes to the locks and limits you've set. If you do forget your passcode, call your program provider for assistance.

- 3 When prompted, enter your passcode again. (This confirms your selection of a passcode number.)
- 4 Select OK to return to the Set Locks and Limits screen.

Your system is now locked, as indicated by the closed padlock () in the Set Locks and Limits screen. All locks and limits you've set are now in effect. The padlock also appears in the Program Banner to remind you of the locked status.

## Overriding the System Lock

You can temporarily override any locks or limits that have been set if you know the system passcode.

For example, if you try to watch a program on a locked station, a message identifies the lock or limit exceeded. After you press the  button, the passcode screen appears. By entering the passcode, you can temporarily unlock the system. The system remains unlocked until you reset the lock.

### To reset a system lock override:

- ☐ Turn off the DSS receiver, and then turn it on again.

The system locks, and all locks and limits are again in effect.


### Note

*If you override the system lock, be sure you reset the lock. If you want to unlock the system on a more permanent basis, follow the procedures under "Unlocking Your System" below.*


## Unlocking Your System

### To unlock a locked system:

- 1 Select SET LOCKS AND LIMITS from the Custom Setup Menu.

The Set Locks and Limits screen appears, with the current settings shown next to each button. The padlock  indicates that the system is currently locked.



- 2 Select UNLOCK from the Set Locks and Limits screen.

SET LOCKS AND LIMITS 	
SPENDING LIMIT	\$10.00
RATINGS LIMIT	PG
STATION LOCK	4 Stations Locked
PPV LOCK	Pay Per View Unlocked
<div>UNLOCK RETURN HELP</div>	

- 3 When the Set Passcode screen appears, enter the correct four-digit passcode.
- 4 Select OK.

Your system is now unlocked, and all locks and limits previously set are no longer in effect.

## Determining the Status of the System Lock

While you're watching programs, you can check the status of the system lock by pressing the DISPLAY button to bring up the Program Banner. If no padlock appears, this means the system is unlocked. A closed padlock  means the system is locked. An open padlock  means the system has been temporarily unlocked using the system lock override.

# Setting Up a List of Custom Stations

If there are stations on the system that you don't usually watch, you can use the Set Custom Stations feature to specify which stations from the Master Guide you want to skip. After you've set skipped stations, they will not appear in the:

- ☐ Custom Guide (a program guide available in the Main Menu)
- ☐ Station Index
- ☐ Stations that appear when you're using the CH+/CH- buttons to change channels

## Note

Skipped stations will continue to be available in the Master Guide and all other program guides.

## To define a list of custom stations:

- 1 Select SET CUSTOM STATIONS from the Custom Setup Menu.
- 2 Select stations that you want to skip.

A station that appears with a checkmark (✓) beside it will be skipped. For example, in the following screen, stations 203, 208, and 213 are set to be skipped.

To set a station so that it is not skipped, just select it again. The checkmark (✓) disappears.

To quickly skip or "unskip" stations, select ALL (to skip all) or NONE (to skip none).

Selecting CANCEL returns you to the previous screen, without saving your selections.

SET CUSTOM STATIONS						
CNN 202	CRT 203 ✓	HLN 204	DTV 205	ESPN 206	DTV 207	ESNa 208 ✓
DTV 209	DTV 210	DTV 211	TNT 212	DTV 213 ✓	DTV 214	E! 215
DTV 216	DTV 217	DTV 218	DTV 219	TCM 220	DTV 221	DIS1 222
DTV 223	DIS2 224	DISC 225	TLC 226	TOON 227	DTV 228	USA 229

OK

CANCEL

ALL

NONE

HELP

## Note

Use the PAGE↑ and PAGE↓ buttons to quickly move through the rows of stations. You can also use the 0-9 buttons to enter the station number directly.

- 3 Select OK when you're finished setting skipped stations.

## To see the results of your Custom Stations settings:

- ☐ Use the Custom Guide (page 31), Station Index (page 36), or CH+/CH- buttons.

# Using the Installation Menu

Read this chapter to set up your DSS receiver for the first time, check the antenna's signal strength, or to run a system test to diagnose any difficulties you may be having with your system.

## Overview

---

The Installation Menu includes several options you can use to set up and troubleshoot your system.

Use the Installation Menu to:

- ☐ Set up and point your satellite antenna (page 59).
- ☐ Replace your access card (page 60).
- ☐ Change the aspect ratio of the DSS receiver to match your TV screen: standard or widescreen (page 62).
- ☐ Run a system test to check the operation of your system, including the access card, phone line, and satellite antenna (page 63)

# Displaying the Installation Menu

To set up your system, first bring up the Installation Menu, as follows:

**1** Press the MENU button to bring up the Main Menu.

**2** Select SYSTEM MENU from the Main Menu.

MAIN MENU		
SELECT GUIDE 1	MASTER GUIDE 2	SELECT LIST 3
MOVIE GUIDE 4	EXIT 5	MOVIE LIST 6
OTHER GUIDES 7	CUSTOM GUIDE 8	SYSTEM MENU 9

**3** Select INSTALLATION MENU from the System Menu.

SYSTEM MENU		
ALTERNATE AUDIO 1	CUSTOM SETUP MENU 2	CANCEL PURCHASE 3
MESSAGES 4	EXIT 5	REVIEW PURCHASES 6
	INSTALLATION MENU 8	MAIN MENU 9

The Installation Menu appears:

INSTALLATION MENU		
	REPLACE ACCESS CARD 2	
SET UP ANTENNA 4	EXIT 5	SET ASPECT RATIO 6
	RUN SYSTEM TEST 8	SYSTEM MENU 9

The following pages describe how to use the Installation Menu to set up your system.

# Setting Up the Satellite Antenna

To install the satellite antenna, or to check the current signal level of the antenna, use the Set Up Antenna screen.

## Note

*Make certain that the signal strength of the satellite antenna is optimized. If the signal is not optimized, you may experience losses in audio or video, especially during rain, snow, or other conditions that tend to degrade signal performance. See the Satellite Antenna Installation Manual for details on using the Set Up Antenna screen to point the dish and optimize the antenna's signal strength.*

Selecting RETURN returns you to the Installation Menu.

- 1 Select SET UP ANTENNA from the Installation Menu.
- 2 The following screen appears.

SET UP ANTENNA

ZIP CODE LAT/LONG TRANSPONDER 2

80 CURRENT LEVEL 85 PEAK LEVEL

LOCKED

RETURN HELP

To determine the elevation and azimuth settings for the satellite antenna, select ZIP CODE or LAT/LONG.

- ☐ **ZIP CODE** uses your five-digit zip code to determine the elevation and azimuth settings.
- ☐ **LAT/LONG** uses your location's latitude and longitude to determine the azimuth and elevation settings.
- ☐ The **Signal Strength Meter** indicates the current signal strength of the antenna.
- ☐ The **Transponder** option allows you to select a transponder number from 1 to 32. You should not need to change this number (the default is 2) unless you're instructed to do so by your program provider.

See the *Satellite Antenna Installation Manual* for details on using the Set Up Antenna screen to point the dish and optimize the antenna's signal strength

- 3 Select RETURN to return to the Installation Menu.

## Replacing Your Access Card

In the event that your program providers need to send you a new access card, use the Replace Access Card option to initialize your new card. During this process, you'll follow the on-screen instructions to copy information from the old card onto the new card. After you initialize the new card, your old card becomes invalid.

### **Warning**

*Do not initialize the access card that comes with your DSS receiver.*


### **To replace your access card:**

- 1 Insert your old access card, if you removed it, as follows:


Open the door to the access card: Place your fingertip in the slot as shown, and gently pull the door down.

### **Caution**

*Handle the door gently to avoid breaking it.*



Then insert the card, arrow side up, as shown, and gently push the door up to close it.






- 2** Select REPLACE ACCESS CARD from the Installation Menu.

INSTALLATION MENU		
	REPLACE ACCESS CARD 2	
SET UP ANTENNA 4	EXIT 5	SET ASPECT RATIO 6
	RUN SYSTEM TEST 8	SYSTEM MENU 9

- 3** When the Replace Access Card screen appears, select OK to begin copying your old access card.

*Selecting RETURN returns you to the Installation Menu, without starting the initialization process.*

REPLACE ACCESS CARD	
	<div>OK</div> <div>RETURN</div> <div>HELP</div>
<div>Please insert OLD access card and select OK to initialize NEW card.</div> <div>CAUTION: After you select OK, you cannot stop this process, and your OLD access card will no longer be valid.</div>	

- 4** Follow the instructions as they are displayed to complete the procedure.

When the message "Replace Access Card Procedure Complete" appears, select OK to return to the Installation Menu.

## Setting the Aspect Ratio

Use the Set Aspect Ratio option to set the DSS receiver's display to match your TV's picture.

### To set the aspect ratio:

- 1 Select SET ASPECT RATIO from the Installation Menu.
- 2 Select one of the options, based on the type of TV you have:
  - ☐ If you have a standard TV, select 4:3.
  - ☐ If you have a wide-screen TV, select 16:9.

*Selecting CANCEL returns you to the Installation Menu, without saving your selection.*

SET ASPECT RATIO		
4:3 ✓	16:9	OK
STANDARD	WIDE	CANCEL
		HELP

- 3 Select OK to return to the Installation Menu.

## Running a System Test

The System Test lets you check the integrity of your system's components, including:

- ☐ Antenna signal
- ☐ System tuning
- ☐ Phone line
- ☐ Access card

Use the System Test if you are experiencing problems with your system.

### To run the System Test:

- 1 Select RUN SYSTEM TEST from the Installation Menu.
- 2 Select TEST.

RUN SYSTEM TEST	
SIGNAL	TEST
TUNING	RETURN
PHONE	HELP
CARD	

The System Test checks all the components automatically, and displays the result of each test.

- 3 Select RETURN to return to the Installation Menu.

### If The System Test Reports Any Problems...

Check your system for any of the following:

- ☐ Check that all cables are connected properly to the DSS receiver.
- ☐ Check that the satellite antenna is installed correctly, and that the signal has been optimized. See the manual that came with the satellite antenna for details.
- ☐ Check that the phone line connected to the DSS receiver is working properly.
- ☐ Check that the access card is inserted properly.

If you cannot resolve problems reported by the System Test, see "Customer Support" on page 2.


## Other Information


This appendix includes supplementary information, including:

- ☐ Locations and descriptions of the controls and indicators on the front and back panels of the DSS receiver (page 66).
- ☐ Remote control button descriptions (page 68).
- ☐ Programming the remote to operate your TV and cable box (page 70).
- ☐ Troubleshooting information (page 72).
- ☐ Precautions (page 74).
- ☐ FCC Information (page 75).
- ☐ Limited warranty (page 76).
- ☐ Specifications (page 77).
- ☐ Index (page 78).


# Location and Function of Controls

## Front Panel



Button	Description
POWER Button	Turns the DSS receiver on and off.
MENU Button	Brings up the Main Menu.
EXIT Button	Clears all on-screen displays, including program guides, menus, etc. If you press EXIT before you complete your selections, the previous selections are restored.
	The arrow buttons highlight items in the on-screen displays (program guides, menus, etc.). The + button selects highlighted items. When pressed during normal DSS-viewing, the + button brings up the Station Index (unless a message appears).
TV/DSS Button	Switches the output of the DSS receiver between TV (normal TV programs), if you've connected a TV cable or antenna, and DSS programs.
Power Indicator	Indicates whether the DSS receiver is on or off.
DSS Indicator	Indicates whether the receiver is set for DSS mode (on) or TV mode (off)
Message Indicator	Indicates you have an unread message.

## Back Panel



Connector	Description	Cable Type
SATELLITE IN	Connects to the LNB on the satellite antenna.	RG6 Coaxial (75-ohm/F-type)
WIDE BAND DATA	Allows you to connect your DSS receiver to new technologies (such as high-definition television), as they are introduced. Additional accessories may be required.	Depends on future applications
CONTROL-S (IN/OUT)	Allows you to pass on remote control signals to another Sony infrared-controlled audio or video component.	Control-S mono miniplug
AUDIO (R)/(L) OUT	Connects your DSS receiver to the right and left audio inputs of your audio or video component.	Audio (2) (RCA-type)
VIDEO OUT	Connects your DSS receiver to your TV or VCR's video input.	Video (RCA-type)
S-VIDEO OUT	Allows you to connect your DSS receiver directly to your TV (if your TV has S-VIDEO IN).	S-Video (4-pin mini DIN)
CH3/CH4 Switch	Determines the TV channel on which programs from the DSS receiver can be viewed.	
UHF/VHF IN	Allows you to connect your DSS receiver to your normal (terrestrial) TV or cable TV service.	RG59 Coaxial (75-ohm/F-type)
VHF(SAT)/UHF OUT	Connects to your TV or VCR.	RG59 Coaxial (75-ohm/F-type)
TEL LINE	Connects your DSS receiver to a telephone jack. This allows you to order pay-per-view programs using the remote control.	Telephone (for RJ-11 jack)
AC IN	Connects your DSS receiver to a 120V AC outlet.	AC


# Using the Remote Control

After you've installed the batteries and programmed the remote control, use these procedures to operate your system components:

- 1** Press the **FUNCTION** button of the component that you want to operate (cable box, TV, or DSS receiver).
- 2** Aim the remote control at the component.
- 3** Press the **POWER** button of the component to turn it on and off.

To control other functions of the component, see the table below.




## Remote Control Button Descriptions



### Note

Buttons highlighted in the following table can also operate your TV or cable box, if the remote has been programmed for these components. See page 70 for instructions on programming the DSS remote.

Button	Description
POWER	<b>CABLE</b> Turns the cable box on and off.
	<b>TV</b> Turns the TV on and off.
	<b>DSS</b> Turns the DSS receiver on and off.
FUNCTION	<b>CABLE</b> Puts the remote in cable mode. In cable mode, the remote operates your cable box.
	<b>TV</b> Puts the remote in TV mode. In TV mode, the remote operates your TV.
	<b>DSS</b> Puts the remote in DSS receiver mode. In DSS mode, the remote operates your DSS receiver.
CODE SET	Used for programming the remote to operate your TV or cable box.
FAVORITE	Brings up the Favorite Station Guide, if you've created one. When pressed repeatedly, cycles through all the Favorite Station Guides that have been created.
TV/VIDEO	Switches the input of the TV.
TV/DSS	Switches the output of the DSS receiver to TV (normal TV programs), if you've connected a TV cable or antenna, or to DSS programs.
JUMP	Tunes to the last station you were tuned to.
0-9	Specifies the station number. In menus, selects the menu item with the corresponding number. Also, in some screens, used to enter numerical values (such as a spending limit or passcode).
DISPLAY	Brings up (or removes) the Program Banner.
ENTER	Used with 0-9 buttons to change stations without any delay in tuning.

Button	Description
EXIT	Clears all on-screen displays, including program guides, menus, etc. If you press EXIT before you complete your selections, the previous selections are restored.
MENU	Brings up the Main Menu.
GUIDE	Brings up the Master Guide. If you're already in a program guide, pressing GUIDE repeatedly brings up future time slots in the guide.
	The arrow buttons highlight items in the on-screen displays (program guides, menus, etc.). The  button selects highlighted items. When pressed during normal DSS-viewing, the  button brings up the Station Index (unless a message appears).
VOL+/-	Raises and lowers the volume on Sony TVs, and TVs in which the remote has been programmed to operate.
CH+/- (PAGE 1/2)	Moves to the next (+) or previous (-) station during normal DSS viewing. In program guides and some setup screens, these buttons page through the on-screen displays.



# Programming the Remote

The DSS receiver's remote control is preset at the factory to operate Sony brand TVs.

If you have a TV other than Sony brand, or you have a cable box you want to control with the DSS receiver's remote, use the following procedures to program the remote to control these components.

## Note

*Your components must have infrared (IR) remote control capability in order to be used with the DSS receiver's remote.*

To program the DSS receiver's remote:

- 1** Manually turn on the component that you want to program.
- 2** Turn to "Programmable Codes" on page 71, and find the three-digit code number for your component. If more than one code number is listed, use the number listed first to complete the following procedures.
- 3** Press the CODE SET button.
- 4** Press the FUNCTION button (CABLE or TV) for the component you're setting up.
- 5** Enter the three-digit code number.
- 6** Press the ENTER button.

*You must perform step 4 within 10 seconds of step 3, or you must start again from step 3.*

*You must perform step 5 within 10 seconds of step 4, or you must start again from step 3. To cancel the operation, press the EXIT button.*

## To Check if the Code Number Works

Use the following procedure to make sure the code you've entered works:

- 1** Aim the DSS receiver's remote at the component and press the POWER button that corresponds to that component.
- 2** If the component responds, try the CH+ and CH- buttons. If the component responds, you're done. Use the space below to record the code numbers for your components.

--	--	--

TV Code

--	--	--

Cable Box Code

If the code doesn't work:

- ☐ Try programming the remote using the other codes listed for your component.
- ☐ If you cannot get your component to respond to the DSS receiver's remote — even after trying all the code numbers for your component — your component may not be compatible with the DSS receiver's remote. If this happens, you must use your component's own remote to operate it.

## Programmable Codes

### TV Codes



Manufacturer	Code
Sony	101
Admiral (M. Wards)	102, 114, 109
ABC	112
Bell & Howell (M. Wards)	114, 109, 138
Brocsonic	103, 112
Craig	122, 123, 120, 121
Croslex	111
Curtis Mathis	103, 119, 123
Daewoo	135, 136, 103
Daytron	113
Emerson	122, 113, 120, 121, 123, 103, 115
Fisher	125
General Electric	102, 118, 103, 107
Goldstar	103, 113, 112, 130
Hitachi	131, 113, 103, 132
JC Penny	103, 102, 130, 107
JVC	128, 129
KTV	133, 113, 103, 123, 134
LXI (Sears)	102, 103, 111, 125, 119, 112
Magnavox	111, 112, 113, 107
Mitsubishi/MGA	124, 103, 112
NEC	103, 112
Panasonic	118, 116, 117, 107
Philco	111, 118, 109
Philips	111
Pioneer	137, 118, 119
Portland	103, 108
Quasar	110, 107
Radio Shack	102, 112, 124, 123
RCA/Proscan	102, 103, 104, 105, 106, 107, 108
Samsung	126, 112, 113, 103
Sanyo	125
Scott	123, 112
Sharp	114, 113, 115

Manufacturer	Code
Signature 2000 (M. Wards)	114, 109
Sylvania	111, 112, 108
Symphonic	123, 139
Toshiba	119, 114
Videch	131, 103, 112
Wards	113, 103, 115, 112
Zenith	108, 110

### Cable Box Codes

Manufacturer	Code
Hamlin/Regal	222, 223, 224, 225, 228
Jerrold/G.I.	201, 202, 203, 204, 205, 206, 207 208, 218
Oak	227, 228, 229
Panasonic	219, 220, 221
Pioneer	214, 215
Scientific Atlanta	209, 210, 211
Tocom	216, 217

# Troubleshooting

Symptom	Possible Causes and Remedies
No picture (poor picture quality or loss of picture)	<ul style="list-style-type: none"> <li><input type="checkbox"/> If you are receiving only stations 100, 200, and 999, call your program providers to have your programming activated.</li> <li><input type="checkbox"/> Check to make sure the DSS receiver is on and set to DSS mode. See page 66.</li> <li><input type="checkbox"/> Check to make sure your access card is inserted properly into the DSS receiver.</li> <li><input type="checkbox"/> Run the System Test to verify that your system is working properly. See page 63.</li> <li><input type="checkbox"/> Check the satellite antenna's signal strength. See page 59.</li> <li><input type="checkbox"/> Check the connections to your TV (and other components). See the Satellite Antenna manual and Chapter 3 of this manual.</li> <li><input type="checkbox"/> Check to make sure your TV (and other components) are set to receive the DSS signal (channel 3 or 4, VIDEO1, etc.), as appropriate to the way your system is connected. See Chapter 3.</li> <li><input type="checkbox"/> Some pay-per-view programs may be protected by Macrovision copy-protection at the discretion of the copyright owner. To ensure a quality picture, make sure that the signal is coming directly from the DSS receiver and not through your VCR. Call your program providers for details.</li> <li><input type="checkbox"/> Make sure the RG-6 cable is properly connected to the antenna's LNB. If the Signal Seeker is not flashing on the LNB, there may be an electrical short in the RG-6 cable and you will need to replace it.</li> </ul>
Cannot access program	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check to make sure that you are subscribing to the station you are trying to tune to. Call your program providers if you are not sure.</li> <li><input type="checkbox"/> Check to make sure the system is not locked. See Chapter 5.</li> <li><input type="checkbox"/> Check to make sure the station isn't set to be skipped. See page 55.</li> </ul>
Cannot order pay-per-view program	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check to make sure you've connected the DSS receiver to a phone line.</li> <li><input type="checkbox"/> It may be too late to purchase this program. Check for other show times. See page 28.</li> <li><input type="checkbox"/> Check to make sure the PPV option is not locked. See Chapter 5.</li> <li><input type="checkbox"/> Your access card may be full. Call your program provider.</li> </ul>
Cannot find the station of the pay-per-view program you've ordered	<ul style="list-style-type: none"> <li><input type="checkbox"/> See "Checking Your Purchase Record" on page 39 to get information (station, start times, etc.) about programs you've ordered.</li> </ul>
Cannot cancel a pay-per-view order via the Cancel Purchase menu option	<ul style="list-style-type: none"> <li><input type="checkbox"/> You cannot cancel pay-per-view orders that you've watched or tuned to. Also, you can cancel only programs you've ordered using the DSS remote control. Call your program providers for details.</li> </ul>
Program guide does not bring up the program you've chosen	<ul style="list-style-type: none"> <li><input type="checkbox"/> You must press the  button to select the program you've highlighted. Although the guide automatically tunes to stations you highlight in any of the guides, you must press the  button to complete your selection.</li> </ul>

Symptom	Possible Causes and Remedies
Cannot bring up the Station Index (↵ button)	<input type="checkbox"/> You cannot bring up the Station Index while a program guide is displayed or if a message such as, "Press ↵ to purchase" appears. Press the EXIT button to clear any on-screen displays. Also, try switching to another non-PPV station.
Cannot display favorite stations	<input type="checkbox"/> You must set up your Favorite Station Guides before favorite stations can be displayed. See page 47.
Ratings limit, spending limit, or pay-per-view lock not working properly	<input type="checkbox"/> Check locks and limits. Then check that the system is locked. See Chapter 5.
Cannot access locks or limits screens	<input type="checkbox"/> The system must be unlocked before you can make changes to the locks and limits. See Chapter 5.
Cannot lock or unlock the system	<input type="checkbox"/> Make sure you've entered the correct passcode. If you've lost or forgotten your passcode, call your program provider. See "Customer Support" on page 2.
Alternate audio track is not available	<input type="checkbox"/> Not all programs offer alternate audio tracks. See page 37.
Language of audio track is incorrect	<input type="checkbox"/> Check default language setting. The program provider may not make available all the languages displayed in the Set Default Language screen. See page 49. Check alternate audio track setting. See page 37.
Cannot record DSS program on VCR	<input type="checkbox"/> Check to make sure the VCR is connected correctly, and that the VCR is set to receive the signal from the DSS receiver. See Chapter 3. <input type="checkbox"/> Make sure you are not trying to record a pay-per-view program that is copy-protected by Macrovision. Some pay-per-view programs are copy-protected at the discretion of the copyright owner. Call your program provider for details.
Main Menu, buttons 4 and 6, do not include the program categories that you want	<input type="checkbox"/> Use SELECT GUIDE to change the program category shown in button 4. Use SELECT LIST to change the program category shown in button 6. See page 29.
Access card problems	<input type="checkbox"/> Check that the card is inserted properly. See page 60. <input type="checkbox"/> Call your program providers. See "Customer Support" on page 2.
Remote control doesn't work	<input type="checkbox"/> To operate your TV or cable box, make sure you've programmed the remote properly. See "Programming the Remote" on page 70. Note: The remote codes may be erased whenever you remove the batteries. Program the remote again if you've removed or replaced the batteries. <input type="checkbox"/> Press the appropriate FUNCTION button (DSS, TV, CABLE) for the component you want to operate. <input type="checkbox"/> Check to make sure the batteries are inserted correctly, and that the batteries are not dead. See page 7.

If you are unable to resolve problems with your system, please see "Customer Support" on page 2 for customer support information and telephone numbers.

# Precautions

---

## On Safety

- ☐ If you spill or drop anything into the cabinet, unplug the receiver and have it checked by qualified personnel before operating it any further.
- ☐ Operate the receiver only on 120 V AC.
- ☐ For detailed safety precautions, see the "Important Safeguards" leaflet that came with the receiver.

## On Power Sources

- ☐ The receiver continues to draw power from the AC power source as long as it is connected to the wall outlet, even if the receiver itself has been turned off.
- ☐ If you are not going to use the receiver for a long time, be sure to disconnect the receiver from the wall outlet. To disconnect the AC power cord, grasp the plug itself; never pull the cord.
- ☐ One blade of the plug is wider than the other for the purpose of safety and will fit into the wall outlet only one way. If you are unable to insert the plug fully into the outlet, contact your dealer.
- ☐ If the AC power cord gets damaged and needs to be replaced, have it done at a qualified service shop only.

## On Placement

- ☐ Place the receiver in a location with adequate ventilation to prevent heat build-up in the receiver and prolong the life of the receiver.
- ☐ Do not place the receiver in a location near heat sources, or in a place subject to direct sunlight, excessive dust, or mechanical shock.
- ☐ Do not place anything on top of the receiver, which might block the ventilation holes and cause malfunctions.
- ☐ Before connecting other components, be sure to turn off and unplug the receiver.

## On Cleaning

- ☐ Clean the cabinet, panel, and controls with a soft cloth slightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder, or solvent such as alcohol or benzene.

## On Repacking

- ☐ Keep the original cartons and packing materials to safely transport the equipment in the future.

# FCC Regulations and Information

## FCC Registration Information

Your digital satellite receiver has been registered by the Federal Communication Commission (FCC) as not being harmful to the telephone network when connected directly to the telephone lines. In order to fully comply with the Rules of the FCC, the following instructions should be read carefully and followed completely where applicable:

- 1 The Federal Communication Commission (FCC) has established Rules which permit this device to be directly connected to the telephone network. Standardized jacks are used for these connections. This equipment should not be used on party lines or coin phones.
- 2 If this device is malfunctioning, it may also be causing harm to the telephone network; this device should be disconnected until the source of the problem can be determined and until repair has been made. If this is not done, the telephone company may temporarily disconnect service.
- 3 The telephone company may make changes in its technical operations and procedures; if such changes affect the compatibility or use of this device, the telephone company is required to give adequate notice of the changes. You will be advised of your right to file a complaint with the FCC.
- 4 If the telephone company requests information on what equipment is connected to their lines, inform them of:
  - a The telephone number to which this unit is connected.
  - b The ringer equivalence number.
  - c The USOC jack required.
  - d The FCC Registration Number.
- 5 Items (b) and (d) are indicated on the label. The Ringer Equivalence Number (REN) is used to determine how many devices can be connected to your telephone line. In most areas, the sum of the RENs of all devices on any one line should not exceed five (5). If too many devices are attached, they may not ring properly.

## Service Requirements

In the event of equipment malfunction, all repairs should be performed by our Company or an authorized agent. It is the responsibility of users requiring service to report the need for service to our company or to one of our authorized agents. For service, call 1-800-838-SONY (7669).

## Radio Interference Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception (which you can determine by turning the equipment off and on), you are encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna (the antenna for radio or television that is receiving the interference)
- ☐ Change the position of the DSS receiver with respect to the radio or television equipment that is receiving the interference
- ☐ Move the DSS receiver away from the equipment that is receiving the interference
- ☐ Plug the DSS receiver into a different outlet so that the DSS receiver and the equipment receiving the interference are on different branch circuits

Shielded cables and I/O cords must be used for this equipment to comply with the relevant FCC regulations. Changes or modifications not expressly approved in writing by Sony Electronics, Inc., void the user's authority to operate this equipment.

If these measures do not eliminate the interference, you should consult your digital satellite system dealer or an experienced radio/television technician for additional suggestions. In addition, you may find the following booklet prepared by the Federal Communications Commission helpful: "How to Identify and Resolve Radio-TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C., 20402 Stock No. 004-000-00345-4.

# Limited Warranty

## Digital Satellite Systems

SONY ELECTRONICS INC. ("SONY") warrants this Product (including any accessories) against defects in material or workmanship as follows:

- 1 **LABOR.** For a period of 90 days from the original date of purchase, if the Product is determined to be defective, SONY will repair or replace the Product at no charge. After this 90 day period, you must pay for all labor charges.
- 2 **PARTS.** For a period of one (1) year from the original date of purchase, SONY will supply, at no charge, new or rebuilt replacements in exchange for defective parts. Any replacements will be warranted for the remainder of the original warranty period or ninety (90) days from installation by SONY's authorized facility, whichever is longer.
- 3 **ACCESSORIES.** Parts and labor for all accessories are for one (1) year.
- 4 **IN-HOME.** For a period of one (1) year from installation date, if the unit was professionally installed by an authorized SONY Digital Satellite System Installer and the LNB (Electronic Antenna Element) fails to function properly, SONY will repair or replace the LNB with a new or rebuilt part. Labor to repair or replace the LNB (after 90 days from purchase) will be at your expense. If no problem is found, or any other item fails, it will be your responsibility to pay the installer their regular rate for an in-home service call.

To obtain warranty service, you must take the Product, or deliver the Product freight prepaid, in either its original packaging or packaging affording an equal degree of protection, to a SONY authorized Digital Satellite System service facility. Please see the telephone number at the end of this section for a number to call to locate the closest facility.

This warranty does not cover customer instruction, installation, setup adjustments or signal reception problems.

This warranty does not cover cosmetic damage or damage due to acts of God, accident, misuse, abuse, negligence, commercial use, or modification of, or to any part of the Product, including the antenna. This warranty does not cover improper installation (if self-installed), loss of use of the product, or wasted programming charges due to product malfunction. This warranty does not cover damage due to improper operation or maintenance, connection to improper voltage supply, or attempted repair by anyone other than a facility authorized by SONY to service the Product. This warranty does not cover Products sold AS IS or WITH ALL FAULTS. This warranty is valid only in the United States.

Proof of purchase in the form of a bill of sale or receipted invoice which is evidence that the unit is within the Warranty period must be presented to obtain warranty service.

---

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. SONY SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. IN NO EVENT SHALL SONY BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT. UNDER NO CIRCUMSTANCES SHALL SONY'S LIABILITY, IF ANY, EXCEED THE PURCHASE PRICE PAID FOR THE PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

---

This warranty is invalid if the factory applied serial number has been altered or removed from the Product.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. In addition, if you enter into a service contract with the SONY Partnership within 90 days of the date of sale, the limitation on how long an implied warranty lasts does not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

For your convenience, SONY ELECTRONICS INC. has established telephone numbers for frequently asked questions. To locate the servicer or dealer nearest you, for assistance or resolution of a service problem, or for product information or operation, call:

**SONY DIGITAL SATELLITE SYSTEM INFORMATION CENTER**

**1-800-838-SONY (7669)**

For an accessory or part not available from your authorized dealer, call:

**1-800-488-SONY (7669)**

# Specifications

<b>Input Jacks</b>	UHF/VHF 75 ohm external terminal Satellite Antenna 75 ohm external terminal CONTROL-S (mini-jack) 5 Vp-p AC Power (120V, 60 Hz)	<b>Supplied Accessories</b>	Remote Commander RM-Y129 (1) Size AA Batteries (2) Access Card (1) Audio/Video Cable (1) RF Cable (1) Telephone Line Cord (1) AC Power Cord
<b>Output Jacks</b>	S-VIDEO OUT 4-pin mini DIN VIDEO (phono jacks) (2) AUDIO R/L (phono jacks) (2) VHF(SAT)/UHF Wide Band Data 15-pin D-Sub Female TEL LINE CONTROL-S (mini-jack)	<b>Optional Sony-brand DSS Accessories</b>	Installation Kit ANJ-DS1 Amplifier EAC-DA1 Diplexer EAC-DD1 Voltage Switch EAC-DV1 Multi-Room A/V Distribution System MDR-D1 Universal Remote Commander RM-Y130 Flat Cable SAK-F1 Coaxial Cable (25 ft.) SAK-C25 Coaxial Cable (75 ft.) SAK-C75
<b>Input Frequency</b>	950 - 1450 MHz		
<b>Power Requirements</b>	AC 120 V		
<b>Power Consumption</b>	23 W max		
<b>Dimensions (w/h/d)</b>	430 x 85 x 290 mm 16.9 x 3.2 x 10.8 inches		
<b>Weight</b>	Set: 3.18kg (7lbs) Unit: 2.56 kg (5.65lbs)		




# Index

0-9 buttons **24, 26, 68**

16:9 aspect ratio **62**

4:3 aspect ratio **62**

 **36, 37**

 **36, 42**

 **36**

 **36**

## A

access card, replacing **60**

alternate audio **37**

alternate audio symbol **36, 37**

antenna

connecting to receiver **14**

setting up **59**

signal level **59**

arrow buttons **9, 66**

aspect ratio, setting **62**

azimuth **59**

## B

back panel connectors **67**

batteries, inserting into remote **7**

baud rate, setting **43**

## C

CH/PAGE buttons **9**

CODE SET button **68**

connecting

audio system **14, 15, 16**

cable TV, terrestrial antenna **14, 15, 16, 18**

home theater system **18**

TV and VCR **16**

TV with A/V jacks **14**

TV with RF jack **14**

CONTROL-S jacks **13**

Custom Guide **31, 55**

Custom Setup Menu, displaying **46**

custom stations, setting **55**

customer support numbers **2**

## D

data services symbol **36, 42**

data services, setting **42**

default language, setting **49**

DISPLAY button **36, 40, 68**

DSS indicator **66**

## E

elevation **59**

ENTER button **68**

EXIT button **10, 11, 27, 34, 66, 69**

Express Navigator **5**

## F

FAVORITE button **27, 35, 68**

Favorite Station Guide

displaying **35**

setting up **47**

features, described **5**

front panel controls **66**

FUNCTION buttons **68**

## G, H, I, J

GUIDE button **9, 24, 26, 69**

Guide format **29**

Highlight and Select, explained **23**

Installation Menu, displaying **58**

JUMP button **36, 68**

## L

languages. See default language and alternate audio.

latitude and longitude, for setting antenna **59**

List format **29**

lock symbol **36**

lock, determining the status **54**

locking the system **53**

locks and limits, setting **50-54**

## M

Macrovision copy-protection **28**

mail. See messages.

Main Menu **24**

## Master Guide

- displaying **9, 24**
- displaying favorite stations in **27**
- exiting **27**
- features **25**
- using **10**

MENU button **24, 66, 69**

menu symbol **24**

message indicator **66**

messages

- erasing **41**
- reading **41**
- receiving **40**

messages symbol **36**

## O

opening, access card door **60**

overriding the system lock **54**

## P

padlock symbol, explained **54**

paging **26**

passcode, setting **53**

pay-per-view

- canceling programs **38**
- free preview **28**
- Macrovision copy-protection **16, 18**
- reviewing purchases **39**
- watching programs **28**

pay-per-view lock

- explained **50**
- setting **52**

POWER button **9, 66**

POWER buttons **68**

power indicator **66**

precautions **74**

problems

- diagnosing **63**
- troubleshooting **72**

Program Banner **36, 40**

program category, selecting **30**

Program guide. See Master Guide.

program provider guides **32**

## R

ratings limit

- explained **50**
- setting **51**

recording DSS programs **20**

remote control

- button descriptions **68**
- inserting batteries **7**

## S

satellite antenna, setting **59**

scrolling **9, 26**

SELECT button **9**

SELECT button, explained **23, 66**

SELECT GUIDE **29**

SELECT LIST **29**

spending limit

- explained **50**
- setting **51**

Station Index

- displaying **9, 11, 33**
- displaying favorite stations in **34**
- exiting **34**
- selecting programs in **11, 34**

station locks

- explained **50**
- setting **52**

S-VIDEO jack **13, 15, 16, 18**

system test, running **63**

## T

transponder **59**

troubleshooting **72**

TV/DSS button **66, 68**

TV/VIDEO button **68**

## U

unlocking the system **54**

## Z

zip code, for setting antenna **59**


# SAT-A/B1

DESCRIPTION: SATELLITE  
RECEIVER  
DIMENSIONS  
(WHD): 16 7/8" X 3 1/2" X 10 7/8"  
WEIGHT: 6 lbs. 4 oz.


POWER  
REQUIREMENTS: 120V  
60  
POWER  
CONSUMPTION: 23  
Wat

1/4 inch = 1 inch Scale 4:1

## FRONT VIEW



## SIDE VIEW



## BACK VIEW



Contractor's  
Notes:

---

---

---

---

---

---

---

---