

Revision C



CHANGING AN INTELLITEC CONTROLLER TO A C-STORM CONTROLLER

1. Insert the 2 wire (GREEN) & 5 wire (BLUE) connector to the corresponding sockets.
2. Cut the ground (GND) wire approx. 4-6 inches from 5pin plug.
3. Connect the J3 wire from Intellitec controller (RED) to existing incoming GND ground to Butt Connector.
4. Connect the 4 inch GND wire from plug connector and an additional 3-4 foot wire of same wire gauge to the chassis frame rail existing ground connection.

Chassis Frame Rail Ground

