



Begin with P1 by aligning registration marks at front cap molding and at floor rail molding. Start at front and work toward rear. Proceed with panels 2, 3, and 4 as shown.

Apply rear as shown.

