



NOTES:

1. TAKE CARE NOT TO SCRATCH PARTS.
2. PREPARE SURFACES FOR POWDER COATING BY PLACING PARTS IN SHAKER WITH ORANGE STONES FOR 30 MINUTES.
3. POWDER COAT WITH M751231 DULL BLACK.

ES58173 POWDER COATING CHARGE



			HWH I-80 EXIT 267 SOUTH RT 1 MOSCOW, IOWA 52760		
			SCALE 1:2	DATE 24MAY18	DRAWN BY
△	23FEB21	WAS ANODIZED	BRACKET: LINKAGE WMT		
NO.	DATE	REVISION			
THE INFORMATION DISCLOSED ON THIS DRAWING IS CONFIDENTIAL AND MUST NOT BE DISCLOSED OR USED IN ANY MANNER WHICH WILL BE DETRIMENTAL TO THE HWH CORPORATION			DRAWING NUMBER AP58173		