

NEWMAR CORPORATION

WARRANTY

DEPARTMENT

PRODUCT INFORMATION BULLETIN

DATE ISSUED	MODEL YEAR(S) AFFECTED	PIB #
12/7/2017	2018	504

MODEL

Bay Star Sport	<input type="checkbox"/>	Ventana	<input type="checkbox"/>	Essex	<input type="checkbox"/>
Bay Star	<input type="checkbox"/>	Dutch Star	<input type="checkbox"/>	King Aire	<input type="checkbox"/>
Canyon Star	<input type="checkbox"/>	Mountain Aire	<input type="checkbox"/>	New Aire	<input checked="" type="checkbox"/>
Ventana LE	<input type="checkbox"/>	London Aire	<input type="checkbox"/>	Other	<input type="checkbox"/>

PRODUCT INFORMATION

Certain 2018 New Aire coaches with floorplan 3343 may have lights under the medicine cabinet wired to the switch located in the accent light panel in the bedroom.

This bulletin is to inform service personnel so they can take the necessary steps to correct the condition if the customer has complained or requested for the lights to be operated using the bathroom light switch instead of the bedroom accent light panel.

To move the lights to the bathroom switch:

- Access the light wiring.
- Disconnect the bedroom accent positive switched 12 volt wire feeding the lights under the medicine cabinet, and cap the feed wire.
- Run a new 16 gauge wire from the lower lights to the vanity light, and wire it to the positive switched vanity light 12 volt wire.
- Wrap the wire with ¼" flexible conduit, and strap it neatly inside the cabinet as needed.
- Test the lights under the medicine cabinet. They should now be turned on or off using the vanity light switch located in the bathroom.