

NEWMAR CORPORATION

WARRANTY DEPARTMENT

TECHNICAL SERVICE BULLETIN

DATE ISSUED	MODEL YEAR(S) AFFECTED	MODEL(S) AFFECTED	TSB #										
03/08/2010	2007-Present	MA,Essex,KG,LA	367										
BRAND			TYPE										
All <input type="checkbox"/>	American Star <input type="checkbox"/>	Mountain Aire <input checked="" type="checkbox"/>	All <input type="checkbox"/> T T <input type="checkbox"/>										
Cypress <input type="checkbox"/>	Dutch Star <input type="checkbox"/>	Kountry Aire <input type="checkbox"/>	F W <input type="checkbox"/> C A <input type="checkbox"/>										
Northern Star <input type="checkbox"/>	Kountry Star <input type="checkbox"/>	Essex <input checked="" type="checkbox"/>	D P <input checked="" type="checkbox"/> D B <input checked="" type="checkbox"/>										
Scottsdale <input type="checkbox"/>	King Aire <input checked="" type="checkbox"/>	London Aire <input checked="" type="checkbox"/>											
All Star ME <input type="checkbox"/>	Ventana <input type="checkbox"/>	Bay Star <input type="checkbox"/>											
<table border="0"><tr><td><input type="checkbox"/> Air Conditioning & Heating</td><td><input type="checkbox"/> Electrical Components</td></tr><tr><td><input type="checkbox"/> Appliances & Accessories</td><td><input checked="" type="checkbox"/> Exterior Components</td></tr><tr><td><input type="checkbox"/> Cabinets & Furniture</td><td><input type="checkbox"/> Interior Components</td></tr><tr><td><input type="checkbox"/> Chassis Components</td><td><input type="checkbox"/> Plumbing & Bath Components</td></tr><tr><td><input type="checkbox"/> Construction Components</td><td><input type="checkbox"/> Windows, Awnings, Vents, & Doors</td></tr></table>				<input type="checkbox"/> Air Conditioning & Heating	<input type="checkbox"/> Electrical Components	<input type="checkbox"/> Appliances & Accessories	<input checked="" type="checkbox"/> Exterior Components	<input type="checkbox"/> Cabinets & Furniture	<input type="checkbox"/> Interior Components	<input type="checkbox"/> Chassis Components	<input type="checkbox"/> Plumbing & Bath Components	<input type="checkbox"/> Construction Components	<input type="checkbox"/> Windows, Awnings, Vents, & Doors
<input type="checkbox"/> Air Conditioning & Heating	<input type="checkbox"/> Electrical Components												
<input type="checkbox"/> Appliances & Accessories	<input checked="" type="checkbox"/> Exterior Components												
<input type="checkbox"/> Cabinets & Furniture	<input type="checkbox"/> Interior Components												
<input type="checkbox"/> Chassis Components	<input type="checkbox"/> Plumbing & Bath Components												
<input type="checkbox"/> Construction Components	<input type="checkbox"/> Windows, Awnings, Vents, & Doors												
DESCRIPTION OF PROBLEM													
Newmar 2007 High Line product with the hanging exterior mirrors, in certain conditions, can have a reflection transferred from the front windshield onto the driver's window.													
RECOMMENDED SOLUTION													
<p>To assist owner request, Newmar Corporation has developed a Plexiglas shield that can be installed to deflect the transferred image.</p> <p><u>Directions for installation:</u></p> <p>1) Place the Plexiglas shield onto the driver's side window trim to determine proper location for installation. Mark 2-3 locations on the forward edge of the shield for the screws to be installed. Pre-drill the holes for the mounting screws with the protective film still attached</p> <p>2) Remove the protective film from both sides of the shield, place the Plexiglas shield back on the window trim in the proper location and use 1/2" self tapping screws to secure the shield in place.</p> <ul style="list-style-type: none">The Newmar part number for the Plexiglas shield is # 017805Flat rate labor time is 3/10's of an hour.													

NEWMAR CORPORATION WARRANTY DEPARTMENT



- Here is the driver's side mirror and pillar post prior to the Plexiglas shield installation.



- 1) Place the Plexiglas shield onto the driver's side window trim to determine proper location for installation. Mark 2-3 locations on the forward edge of the shield for the screws to be installed. Pre-drill the holes for the mounting screws with the protective film still attached.



- 2) Remove the protective film from both sides of the shield, place the Plexiglas shield back on the window trim in the proper location and use 1/2" self tapping screws to secure the shield in place.

If you have any questions regarding this T.S.B., please contact a Warranty Service Representative at Newmar Corporation.