

NEWMAR CORPORATION WARRANTY DEPARTMENT

TECHNICAL SERVICE BULLETIN																	
DATE ISSUED		MODEL YEAR(S) AFFECTED		MODEL(S) AFFECTED		TSB #											
04/21/2010		2006-2007		Dutch Star		370											
BRAND						TYPE											
All	<input type="checkbox"/>	American Star	<input type="checkbox"/>	Mountain Aire	<input type="checkbox"/>	All	<input type="checkbox"/>										
Cypress	<input type="checkbox"/>	Dutch Star	<input checked="" type="checkbox"/>	Kountry Aire	<input type="checkbox"/>	T T	<input type="checkbox"/>										
Northern Star	<input type="checkbox"/>	Kountry Star	<input type="checkbox"/>	Essex	<input type="checkbox"/>	F W	<input type="checkbox"/>										
Scottsdale	<input type="checkbox"/>	King Aire	<input type="checkbox"/>	London Aire	<input type="checkbox"/>	C A	<input type="checkbox"/>										
All Star ME	<input type="checkbox"/>	Ventana	<input type="checkbox"/>	Bay Star	<input type="checkbox"/>	D P	<input checked="" type="checkbox"/>										
						D B	<input type="checkbox"/>										
<table border="0"><tr><td><input type="checkbox"/> Air Conditioning & Heating</td><td><input type="checkbox"/> Electrical Components</td></tr><tr><td><input type="checkbox"/> Appliances & Accessories</td><td><input checked="" type="checkbox"/> Exterior Components</td></tr><tr><td><input type="checkbox"/> Cabinets & Furniture</td><td><input type="checkbox"/> Interior Components</td></tr><tr><td><input type="checkbox"/> Chassis Components</td><td><input type="checkbox"/> Plumbing & Bath Components</td></tr><tr><td><input type="checkbox"/> Construction Components</td><td><input type="checkbox"/> Windows, Awnings, Vents, & Doors</td></tr></table>								<input type="checkbox"/> Air Conditioning & Heating	<input type="checkbox"/> Electrical Components	<input type="checkbox"/> Appliances & Accessories	<input checked="" type="checkbox"/> Exterior Components	<input type="checkbox"/> Cabinets & Furniture	<input type="checkbox"/> Interior Components	<input type="checkbox"/> Chassis Components	<input type="checkbox"/> Plumbing & Bath Components	<input type="checkbox"/> Construction Components	<input type="checkbox"/> Windows, Awnings, Vents, & Doors
<input type="checkbox"/> Air Conditioning & Heating	<input type="checkbox"/> Electrical Components																
<input type="checkbox"/> Appliances & Accessories	<input checked="" type="checkbox"/> Exterior Components																
<input type="checkbox"/> Cabinets & Furniture	<input type="checkbox"/> Interior Components																
<input type="checkbox"/> Chassis Components	<input type="checkbox"/> Plumbing & Bath Components																
<input type="checkbox"/> Construction Components	<input type="checkbox"/> Windows, Awnings, Vents, & Doors																
DESCRIPTION OF PROBLEM																	
Newmar 2007 Standard Line product with the hanging exterior mirrors, in certain conditions, can have a reflection transferred from the front windshield onto the driver's window.																	
RECOMMENDED SOLUTION																	
<p>To assist owner request, Newmar Corporation has developed a Plexiglas shield that can be installed to deflect the transferred image.</p> <p style="text-align: center;"><u>Directions for installation:</u></p> <p>1) Place the Plexiglas shield onto the driver's side window trim to determine proper location for installation. Mark 2-3 locations on the forward edge of the shield for the screws to be installed. Pre-drill the holes for the mounting screws with the protective film still attached</p> <p>2) Remove the protective film from both sides of the shield, place the Plexiglas shield back on the window trim in the proper location and use 1/2" self tapping screws to secure the shield in place.</p> <ul style="list-style-type: none">• The Newmar part number for the Plexiglas shield is # <u>017805</u>• Flat rate labor time is 3/10's of an hour.																	

NEWMAR CORPORATION WARRANTY DEPARTMENT



- Here is the driver's side mirror and pillar post prior to the Plexiglas shield installation.



- 1) Place the Plexiglas shield onto the driver's side window trim to determine proper location for installation. Mark 2-3 locations on the forward edge of the shield for the screws to be installed. Pre-drill the holes for the mounting screws with the protective film still attached.



- 2) Remove the protective film from both sides of the shield, place the Plexiglas shield back on the window trim in the proper location and use 1/2" self tapping screws to secure the shield in place.

If you have any questions regarding this T.S.B., please contact a Warranty Service Representative at Newmar Corporation.