




SPARE PARTS CATALOG

Fourth Edition – February 2006

LAUNDRY PRODUCTS



Washer


MODEL

EW510 (WHITE / PLATINUM)

☆ ***TABLE OF CONTENTS*** ☆

• <i><u>CABINET</u></i>	3 - 4
• <i><u>TUB & DRUM</u></i>	5 - 6
• <i><u>CONTROLS</u></i>	7 - 9

EXPLODED VIEW 1: CABINET




Spare parts list : EW510 (WHITE / PLATINUM)**Table I-Cabinet & Porthole**

Pos#	PART#	DESCRIPTION
01	00703	Back panel -White
01	01703	Back panel -Platinum
03	30803	Top panel assembly-White
03	31803	Top panel assembly-Platinum
04	00784	Clamp for drain hose and power cable
05	30709	Control panel -White
05	31709	Control panel -Platinum
06	00792	Push Button -White
06	01792	Push button -Platinum
07	00749	Light cover
08	00801	Washer Knob - White
08	01801	Washer knob-Platinum
09	00800	Spin speed selector knob-White
10	10725	Soap Dispenser handle-White
10	11725	Soap Dispenser handle-Platinum
11	00750	Electric door switch
12	00755	Door handle catch
13	00766	Door handle catch pin
14	00767	Door handle catch spring
15	00770	Door handle
16	00772	Door Inner frame -White
16	01772	Door Inner frame -Platinum
17	00769	Door Safety glass
18	00768	Door Outer trim -White
18	01768	Door Outer trim -Platinum
19	00789	Support for hinge
20	00771	Door hinge assembly
21	00747	Kick plate -White
21	01747	Kick plate -Platinum
22	00816	Bottom panel(interior)
23	00734	Feet
24	00787	Support for capacitor
25	00710	Bracket for capacitor
26	00785	screw
27	00790	Support for speed regulator

Spare parts list : **EW510 (WHITE / PLATINUM)**

EXPLODED VIEW 2: TUB & DRUM




Spare parts list : EW510 (WHITE / PLATINUM)***Table 2 - Tub & Drum***

Pos#	PART#	DESCRIPTION
01	30811	Tub assy
02	00729	Drum Assy
03	00812	Tub Gasket
04	00813	Tub front flange
05	00818	Back tub ring assy
06	00778	Porthole Diaphragm (Boot)
07	00735	Front counterweight
08	00722	Detergent recycling hose
09	00741	Hose - tub to pump
10	30740	Hose - soap dispenser to tub
11	00795	Shock absorber
12	00796	Shock absorber support
13	00797	Shouldered rubber bush
14	00783	Rubber cup washer
15	00815	Tub suspension spring
16	00798	Spring rest
17	00817	Upper counterweight
18	00781	Retaining ring
19	00782	Ball bearing 6204
19	00829	Ball bearing 6205
20	00814	Cross bearing assembly
21	00724	Pulley assembly
22	00777	Drive belt
23	00780	Porthole diaphragm clamp
24	00779	Clamp -Porthole diaphragm & tub
27	00704	Bolt –Drum Pulley Fixing

Spare parts list : EW510 (WHITE / PLATINUM)

EXPLODED VIEW 3: CONTROLS



Spare parts list : EW510 (WHITE / PLATINUM)**Table 3 - Controls**

Pos#	PART#	DESCRIPTION
01	30728	Spin speed selector
02 / 05 / 45	00775	Hose(to pressure switch)
03	00774	Pressure switch(small)
04	01774	Pressure switch(large)
06	10819	Washer timer
07	00823	"Y" coupling
08	00805	Transmission to detergent tray
09	00713	Cam follower
10	00712	Bush to timer cam
11	00802	Timer cam
12	00716	Power cord
13	00776	Drain Pump
14 / 15	00714	Capacitor
16	00751	Main Motor
17	00754	Nut M6
18	00753	Motor spacer
19	00711	Bush for motor
20	00752	Motor bolt M6X212
21	00788	Support for drain hose
22	00727	Drain hose
23	30822	Wiring assembly
24	00742	Hopper
25	00810	Tube between solenoid valve and detergent tray
26	00806	"T" coupling
27	00746	Inlet water hose
28	00723	Detergent tray
29	00719	Cover for detergent tray
30	00748	Light bulb
31	00743	Hopper cover
32	00726	Dispenser spring
33	00804	Transmission for dispenser
34	00731	Ejector guide
35	00730	Ejector
36	00799	Push button - No Spin

Spare parts list : **EW510 (WHITE / PLATINUM)**

Table 3 - Controls (Contd....)

Pos#	PART#	DESCRIPTION
37	01799	Push button - Half load
38	02799	Push button - On/Off
39	20820	Cold water valve
40	00821	Hot water valve
41	00773	Pressure reducing valve
42	00786	Sponge for hose to pressure switch
43	00702	Air trap
44	00717	Clamp for air trap
46	00701	3 poles terminal board-ALL
47	00791	Electronic module

COMPANY INFORMATION

EQUATOR CONTACT NUMBERS

**SERVICE, PARTS,
ACCESSORIES & DETERGENT ORDERING:
(800) 776-3538**

TECHNICAL SUPPORT: (888) 935-1565