



Part No. **42036/
42037**

RV Toilets

Style II® Seat & Cover Kit

Made in the USA

Thetford Corporation

Ann Arbor, MI **1-800-521-3032** www.thetford.com

F# 42100 12/06

Kit Contains

- ✓ Seat & Cover (PN 42036 or 42037)
- ✓ Closet flange seal (PN 02125)
- ✓ Instruction sheet (PN 42100)

Needed

- ✓ Towel(s)
- ✓ Plastic trash bag
- ✓ Flat-head screwdriver
- ✓ 1/2-inch wrench

Before Beginning

- ✓ Read all instructions completely.
- ✓ Reduce holding tank odor: Rinse toilet with water, drain holding tank, and add Thetford Holding Tank Deodorant.
- ✓ Wear protective gloves, glasses, long sleeves, and nose/face mask to avoid contact with human waste.
- ✓ Wash entire toilet thoroughly.
- ✓ Refer to Figures 1 and 2 for component locations. Style Lite shown.

Note: You may not need to remove the toilet if you have adequate access to the back of toilet and Nut on underside of Bowl.

Remove Toilet

1. Turn off RV water supply per RV Owner's Manual.
2. Flush toilet to drain.
3. Place towel(s) behind toilet under water connection to catch water.
4. Disconnect RV water supply from toilet.
5. Remove Closet Flange Bolt Covers (if present) and Nuts.
6. Lift Toilet from floor and place on trash bag.
7. Cover holding tank opening with a towel.
8. Remove old closet flange Seal. Discard.

Remove old Seat & Cover

1. Flip up Hinge Caps.
2. While holding Nut on underside of Bowl, use flathead screwdriver to remove Bolt from Nut and Washers. Discard.
3. Remove Seat & Cover. Discard.

Install new Seat & Cover

1. Position new Washer on top of hole opening. Position Seat & Cover, placing new Bolt through hinge and Washer.
2. At underside, place new Washer and Nut on Bolt. Hand tighten. Secure with screwdriver.
3. Lock Hinge Caps in place.

Reinstall Toilet

1. Install new Closet Flange Seal, lip side down, on toilet.
2. Uncover holding tank opening and remove towel(s).
3. Place Toilet on floor, aligning mounting holes with closet bolts.
4. Tighten Closet Flange Nuts until toilet does not rock. *Do not overtighten.*
5. Replace Bolt Covers (if present).
6. Connect RV water supply line to Toilet.
7. Turn on RV water supply.
8. Flush test Toilet, checking for leaks at all connections.