




INDEX NO	PART NUMBER	DESCRIPTION
1	3307862.007(X)	Cap, Lead Rail RH
2	3307861.009(X)	Cap, Lead Rail LH
3	3108709.365	Kit, Asm, Spring Arm Brkt (2 req)
4	3307864.003	Arm, Spring RH
5	3307863.005	Arm, Spring LH
6	3104675.016	Cap, Roller Tube RH
7	3108710.108-MANUAL	Cap Roller Tube LH
8	3109764.021(X)	Cover, Back Motor
9	3109549.166(X)	Cover, Front Motor
10	3109628.001(X)	Arm Support, Front
11	3109549.125(X)	Cover, RH
12	3105794.014	Plate, RH End
13	3307875.009	Rivet, Plastic Push
14	3307867.006	Plate, Bearing LH
15	3309007.007	Asm., Winch Motor
16	*R3107540(XX).053	Fabric, Acrylic
	*R3108165(YY).053	Fabric, Vinyl
17	730361.001-(X)	Rail, Awning 50-1/2"

CUSTOMER OPTIONS

3109688.006	Kit, Adapter
3307843.007	Kit, Control Box

Replace (X) with "B" for Polar White, "H" for Mende, "R" for Champagne, "S" for Satin, "U" for Black, "V" for Gold
 Replace (XX) with Acrylic Letter Code from Color Code Chart on page 2.
 Replace (YY) with Vinyl Letter Code from Color Code Chart on page 2.
 *Replace the Prefix Letter "R" with "B" for boxed fabric.