




INDEX NO	PART NUMBER	DESCRIPTION
1	3307862.007(X)	Cap, Lead Rail RH 011670
2	3307861.009(X)	Cap, Lead Rail LH 011572
3	3108709.365	Kit, Asm, Spring Arm Brkt (2 req)
4	3307864.003	Arm, Spring RH 07652
5	3307863.005	Arm, Spring LH 07797
6	3104675.016	Cap, Roller Tube RH
7	3108710.108	Cap Roller Tube LH 012195
8	3109764.021(X)	Cover, Back Motor 012000
9	3109549.166(X)	Cover, Front Motor 011607
10	3109628.001(X)	Arm Support, Front
11	3109549.125(X)	Cover, RH 011695
12	3105794.014	Plate, RH End 012195
13	3307875.009	Rivet, Plastic Push 010074
14	3307867.006	Plate, Bearing LH 08507
15	3307874.006	Asm., Winch Motor 06963
16	*R3107540(XX).053	Fabric, Acrylic 06019
	*R3108165(YY).053	Fabric, Vinyl
17	730361.001-(X)	Rail, Awning 50-1/2"

CUSTOMER OPTIONS

3109688.006	Kit, Adapter
3307843.007	Kit, Control Box

Replace (X) with "B" for Polar White, "H" for Mende, "R" for Champagne, "S" for Satin, "U" for Black, "V" for Gold
 Replace (XX) with Acrylic Letter Code from Color Code Chart on page 2.
 Replace (YY) with Vinyl Letter Code from Color Code Chart on page 2.
 *Replace the Prefix Letter "R" with "B" for boxed fabric.