


LITERATURE NUMBER MPD 50124

**GASKET KIT** 

PHONE: 574·264·2131 FAX: 574·206·9713 INTERNET: http://www.atwoodmobile.com

**SEALED BURNER RANGE** 

Effective 11/21/07



For complete Range & Cooktop instructions consult MPD 57279.

## KIT # MPD 50140

- Unlatch and lift top according to instructions in the instruction manual MPD 57279.
- 2. For each burner tube (C), carefully place one (1) ceramic fiber gasket (A) on burner tube collar flange (B).
- Replace top. Assure all burner tubes line up and insert into burner heads.