




FRENCH DOOR BOTTOM MOUNT REFRIGERATOR

MODELS:

WRF560SEYW04 (White)
WRF560SEYB04 (Black)
WRF560SEYM04 (Monochromatic Stainless)

CABINET PARTS




CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10596094	Service & Wiring Sheet
	W10727388	Energy Guide
	W10360467	Use and Care Guide
	2225623	Icemaker Service Sheet
2		Hinge, Top
	W10546298	Left Hand
	W10546299	Right Hand
3		Roller, Front
	W10359256	Left Hand
	W10359255	Right Hand
4	W10735398	Filter, Water
5	W10817430	Housing, Water Filter
6	W10306392	Cover, Water Filter
7	489497	Screw
8		Cover, Toe Grille
	W10339257	White
	W10353930	Black
	W10353932	Grey
9	489442	Screw
10	W10141622	Brake, Roller

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10740689	Tube, Filter Inlet
12	549193	Clamp, Power Cord
13	489497	Screw
14		Hinge, Center
	W10770878	Left Hand
	W10770877	Right Hand
15	W10450363	Shim, Center Hinge
16	2262176	Screw
17		Rail, Center (Not Serviced)
18		Fitting, Water Tube (Not Serviced)
19	W10636716	Cover, Unit
20		Filler, Corner
	W10283959	White
	W10283960	Black
	W10283961	Grey
21		Grille
	W10300127	White
	W10353933	Black
	W10353935	Grey
22	1106508	Gasket, Seal
23	W10601149	Fitting, Water Tube

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
24	W10667756	Tube, Filter Outlet
25		Cover, Hinge
	W10465765	Left Hand (White)
	W10465764	Right Hand (White)
	W10465771	Left Hand (Black)
	W10465770	Right Hand (Black)
	W10465768	Left Hand (Grey)
	W10465767	Right Hand (Grey)
26		Cabinet (Not a Serviceable Part)
27	2174706	Clip, Roller
28	W10463317	Tube, Cabinet Water
29	W10331226	Drum, Toe Grille
30	W10329003	Clamp, Tube
31	2181939	Insert, Tube
32	W10498992	Valve, Inlet
33	W10496649	Tube, Water
34	W10237915	Bracket, Water Valve
35	W10279866	Assembly, Dual Valve


LINER AND ICEMAKER PARTS



LINER AND ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	16	W10300900	Cover, Evaporator	31	W10313917	Housing, Freezer Lighting
2	2197380	Grommet	17	W10317182	Tower, Freezer	32	W10313918	Lens, Light
3	W10468762	Gasket, Evaporator Cover	18	W10383615	Thermistor, Freezer Evaporator	33	W10440814	Socket, Light
4	W10360497	Assembly, LED Light	19	1118894	Switch, Rocker Arm	34	W10809513	Bulb, Light
5	W10469878	Housing, Light	20	W10413160	Cover, Water Reservoir	35	W10745484	Damper, Electronic Control
6	W10798439	Container, Water Reservoir	21	W10568672	Reservoir, Water	36	W10474774	Cover, Damper Housing
7	12466105	Switch, Light	22	W10271543	Connector, Water Tube	37	W10314204	Housing, Damper
8	W10487766	Assembly, Freezer Wire	23	W10425252	Cover, Thermistor	38	W10448448	Assembly, Multiflow
9	W10459385	Cover, Control Housing	24	W10330850	Grille, Air Filter Bottom	39	W10384183	Thermistor
10	W10464673	Motor, Fan	25	W10315189	Filter, Air	40	W10289690	Cover, Icemaker
11	2200509	Blade, Fan	26	W10356895	Tower, Multiflow Air	41	W10474785	Arm, Shut Off
12	W10453580	Housing, Control	27	W10314195	Shield, Heat	42	W10309400	Assembly, Ice Maker Wire
13	W10336009	Cup, Screw	28	W10321162	Bracket, Fan Motor	43	W10632400	Assembly, Icemaker
14	W10421353	Assembly, Refrigerator Lighting Wire	29	489478	Screw	44	W10378263	Pan, Ice
15	488208	Screw	30	2254454	Bracket, Evaporator Fan Rear			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Includes #8)	5		Badge, Whirlpool	11	W10462299	Caddy, Condiment
	W10557489	Left Hand (White)		W10481434	White	12	W10326335	Bin, Shallow
	W10353181	Right Hand (White)		W10481433	Grey	13		Assembly, Flipper
	W10557491	Left Hand (Black)	6	W10470155	Closure, Door		W10624451	Mullion White
	W10413518	Right Hand (Black)	7	W10308869	Bin, Medium		W10624448	Black
	W10557493	Left Hand (Stainless)	8		Gasket, Door		W10624450	Grey
	W10413519	Right Hand (Stainless)		W10353189	Beige	14	12990302	Screw
2		Stop, Door		W10413465	Black	15	W10010140	Set Screw (Silver)
	2189202	Left Hand		W10413468	Grey	16	W10170540	Screw
	W10397055	Right Hand	9		Assembly, Handle			
3	489276	Screw		W10686459	White			
4	W10366270	Thimble, Top (White)		W10686442	Black			
				W10686482	Stainless			
			10	W10317224	Compartment, Utility			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Items 2 & 3)	3		Gasket, Door	4		Assembly, Handle
	W10433606	White		W10465758	Beige		W10686485	White
	W10433607	Black		W10465761	Black		W10686483	Black
	W10433608	Stainless		W10465762	Grey		W10686487	Stainless
2	W10334042	Thimble, Top (Black)				5	W10170540	Screw
						6	W10010140	Set Screw (Silver)



UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10300116	Baseplate	19	8533859	Screw	37	489478	Screw
2	2319835	Grommet, Condenser	20	W10236396	Strap, Compressor	38	W10314197	Bracket, Evaporator
3	W10342567	Condenser	21	W10174384	Strap, Bale	39	2219077	Clip, Harness
4	W10436849	Heater, Defrost	22	2315541	Bracket, Condenser Fan	40	W10519112	Valve, Drain
5	W10321158	Assembly, Evaporator	23	W10530280	Motor, Condenser	41	2215468	Insulation, Sound
6	8533961	Screw	24	W10633276	Assembly, Unit Wire	Following Parts Not Illustrated 978025 Valve, Access 978026 Valve, Access 978027 Valve, Access 978028 Valve, Access 978029 Valve, Access 978030 Valve, Access 876764 Valve, Access REFRIGERANT CHARGE 4.25 oz (R-134A)		
7	W10314195	Shield, Heat	25	W10817071	Blade, Fan			
8	W10271541	Connector, Union	26	VS20001	Tube, Process			
9	W10314199	Tube, Drain	27	488500	Screw			
10	W10248621	Clip, Condenser	28	W10445423	Compressor			
11	W10424230	Assembly, Low Voltage Wire	29	W10669573	Drier			
12	W10547719	Control, Electronic	30	W10349514	Cover, Condenser Bottom			
13	2323186	Box, Control	31	W10815861	Clip, Bottom Cover			
14	10835903SP	Grommet, Compressor	32	W10590083	Capacitor			
15	W10448874	Device, Start	33	W10802027	Tray, Drain			
16	W10313215	Cover, Electronic Control	34	W10510988	Tube, Suction			
17	W10475495	Roller	35	2263990	Tie, Wire			
18	2179826	Axle, Rivet	36	2258429	Heat Probe			


SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10486290	Assembly, Full Shelf (30")	11	W10513681	Glass, Pantry Cover	21	W10802342	Shaft, Rack
2	W10502933	Assembly, 2/3 Flip Shelf	12	W10397907	Assembly, Pantry Deli Pan	22	W10277361	Collar, Gear
3	W10468557	Rail, Track (Center)	13	W10397908	Rail Pantry (Left Hand)	23		Adaptor, Freezer
4	W10313893	Shelf, 2/3 Flip	14	W10414530	Rail, Pantry (Right Hand)		W10397636	Left Hand
5	W10468556	Rail, Track (Right Hand)	15	W10278139	Roller		W10397635	Right Hand
6	W10468555	Rail, Track (Left Hand)	16	W10411411	Control, Temperature	24	W10346771	Filter, Produce Preserver
7	W10370327	Pan, Crisper (16")	17	W10507470	Assembly, Pantry Cover Support			
8	W10317184	Pan, Crisper (8")	18	W10555437	Bin, Upper Freezer			
9	W10408748	Holder, Produce Filter	19	W10257246	Axle, Roller			
10	W10356844	Control, Humidity	20	W10317289	Basket, Lower Freezer			

DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	5	W10689399	Assembly, User Interface	9	W10356017	Ring, Trim
2		Drip Tray	6		Cover, Separator	10	2305235	Assembly, Spigot
	W10300448	White		W10356029	Chromium Frost	11	W10445080	Tube, Water Dispenser
	W10356018	Black	7		Assembly, Single Pad			
	W10356019	Grey		W10433547	White			
3	W10300437	Separator		W10433546	Black			
4		Fascia, Sparsh		W10433548	Grey			
	W10435575	Silver Mirror	8	W10735841	Assembly, Dispenser Wire			
	W10435576	Black						

OPTIONAL PARTS

FOLLOWING PARTS NOT ILLUSTRATED

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	511873	White Porcelain (2 oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	606755	Bag
	503695	Cork, Sealer

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key




REFRIGERATOR

MODELS:

WRF560SEYW04 (White)
WRF560SEYB04 (Black)
WRF560SEYM04 (Monochromatic Stainless)

CABINET PARTS




CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10596094	Service & Wiring Sheet
	W10727388	Energy Guide
	W10360467	Use and Care Guide
	2225623	Icemaker Service Sheet
2		Hinge, Top
	W10546298	Left Hand
	W10546299	Right Hand
3		Roller, Front
	W10359256	Left Hand
	W10359255	Right Hand
4	W10569758	Water Filter
5	W10346257	Housing, Water Filter
6	W10306392	Cover, Water Filter
7	489497	Screw
8		Cover, Toe Grille
	W10339257	White
	W10353930	Black
	W10353932	Grey
9	489442	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10141622	Brake, Roller
11	W10449619	Tube, Filter Inlet
12	549193	Clamp, Power Cord
13	489497	Screw
14		Hinge, Center
	W10521411	Left Hand
	W10521409	Right Hand
15	W10450363	Shim, Center Hinge
16	2262176	Screw
17		Rail, Center (Not Serviced)
18		Fitting, Water Tube (Not Serviced)
19	W10636716	Cover, Unit
20		Filler, Corner
	W10283959	White
	W10283960	Black
	W10283961	Grey
21		Grille
	W10300127	White
	W10353933	Black
	W10353935	Grey

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
22	1106508	Gasket, Seal
23	W10601149	Fitting, Water Tube
24	W10449617	Tube, Filter Outlet
25		Cover, Hinge
	W10465765	Left Hand (White)
	W10465764	Right Hand (White)
	W10465771	Left Hand (Black)
	W10465770	Right Hand (Black)
	W10465768	Left Hand (Grey)
	W10465767	Right Hand (Grey)
26		Cabinet (Not a Serviceable Part)
27	2174706	Clip, Roller
28	W10463317	Tube, Cabinet Water
29	W10331226	Drum, Toe Grille


LINER PARTS



LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	16	W10300900	Cover, Evaporator	31	W10313917	Housing, Freezer Lighting
2	2197380	Grommet	17	W10317182	Tower, Freezer	32	W10313918	Lens, Light
3	W10468762	Gasket, Evaporator Cover	18	W10383615	Thermistor, Freezer Evaporator	33	W10440814	Socket, Light
4	W10360497	Assembly, LED Light	19	1118894	Switch, Rocker Arm	34	W10473925	Bulb, Light
5	W10469878	Housing, Light	20	W10413160	Cover, Water Reservoir	35	W10257451	Damper, Electronic Control
6	W10326338	Container, Water Reservoir	21	W10426134	Reservoir, Water	36	W10474774	Cover, Damper Housing
7	12466105	Switch, Light	22	W10271543	Connector, Water Tube	37	W10314204	Housing, Damper
8	W10487766	Assembly, Freezer Wire	23	W10425252	Cover, Thermistor	38	W10448448	Assembly, Multiflow
9	W10459385	Cover, Control Housing	24	W10330850	Grille, Air Filter Bottom			
10	W10464673	Motor, Fan	25	W10315189	Filter, Air			
11	2200509	Blade, Fan	26	W10356895	Tower, Multiflow Air			
12	W10453580	Housing, Control	27	W10314195	Shield, Heat			
13	W10336009	Cup, Screw	28	W10321162	Bracket, Fan Motor			
14	W10421353	Assembly, Refrigerator Lighting Wire	29	489478	Screw			
15	488208	Screw	30	2254454	Bracket, Evaporator Fan Rear			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Refrigerator Door (Includes #8)	5		Badge, Whirlpool	10	W10317224	Compartment, Utility
	W10353174	Left Hand (White)		W10481434	White	11	W10462299	Caddy, Condiment
	W10353181	Right Hand (White)		W10481433	Grey	12	W10326335	Bin, Shallow
	W10413521	Left Hand (Black)	6	W10470155	Closure, Door	13		Assembly, Flipper
	W10413518	Right Hand (Black)	7	W10308869	Bin, Medium		W10624451	Mullion White
	W10413523	Left Hand (Stainless)	8		Gasket, Door		W10624448	Black
	W10413519	Right Hand (Stainless)		W10353189	Beige		W10624450	Grey
2	2189202	Bracket, Door Stop		W10413465	Black	14	12990302	Screw
3	489276	Screw		W10413468	Grey	15	W10287054	Screw, Set
4	W10366270	Thimble, Top (White)	9		Assembly, Handle	16	W10170540	Screw
				W10357233	White			
				W10398786	Black			
				W10356566	Stainless			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Items 2 & 3)	3		Gasket, Door	4		Assembly, Handle
	W10433606	White		W10465758	Beige		W10357241	White
	W10433607	Black		W10465761	Black		W10389516	Black
	W10433608	Stainless		W10465762	Grey		W10357240	Stainless
2	W10334042	Thimble, Top (Black)				5	W10378263	Pan, Ice
						6	W10287054	Screw, Set
						7	W10170540	Screw



UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10300116	Plate, Unit Mounting	20	W10236396	Strap, Compressor	40	W10519112	Valve, Drain
2	2319835	Grommet, Condenser	21	W10174384	Strap, Bale	41	2215468	Insulation, Sound
3	W10342567	Condenser	22	2315541	Bracket, Condenser Fan	Following Parts Not Illustrated		
4	W10436849	Heater, Defrost	23	W10508362	Motor, Condenser			
5	W10321158	Assembly, Evaporator	24	W10390391	Assembly, Unit Wire			
6	8533961	Screw	25	W10139483	Blade, Fan			
7	W10314195	Shield, Heat	26	VS20001	Tube, Process			
8	W10271541	Connector, Union	27	488500	Screw			
9	W10314199	Tube, Drain	28	W10445423	Compressor			
10	W10248621	Clip, Condenser	29	W10669573	Drier			
11	W10424230	Assembly, Low Voltage Wire	30	W10349514	Cover, Condenser Bottom			
12	W10547719	Control, Electronic	31	W10296661	Clip, Bottom Cover			
13	W10370696	Enclosure, Electronic Control	32	W10590083	Capacitor	REFRIGERANT CHARGE 4.25 oz (R-134A)		
14	10835903	Grommet	33	W10466213	Tray, Drain			
15	W10448874	Device, Start	34	W10510988	Tube, Suction			
16	W10313215	Cover, Electronic Control	35	2263990	Tie, Wire			
17	W10475495	Roller	36	2258429	Heat Probe			
18	2179826	Axle, Rivet	37	489478	Screw			
19	8533859	Screw	38	W10314197	Bracket, Evaporator			
			39	2219077	Clip, Harness			


SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10486290	Assembly, Full Shelf (30")	11	W10513681	Glass, Pantry Cover	21	W10371538	Shaft, Rack
2	W10502933	Assembly, 2/3 Flip Shelf	12	W10397907	Assembly, Pantry Deli Pan	22	W10277361	Collar, Gear
3	W10468557	Rail, Track (Center)	13	W10317191	Rail, Pantry (Left Hand)	23		Adaptor, Freezer
4	W10313893	Shelf, 2/3 Flip	14	W10317189	Rail, Pantry (Right Hand)		W10397636	Left Hand
5	W10468556	Rail, Track (Right Hand)	15	W10278139	Roller		W10397635	Right Hand
6	W10468555	Rail, Track (Left Hand)	16	W10411411	Control, Temperature	24	W10346771	Filter, Produce Preserver
7	W10370327	Pan, Crisper (16")	17	W10507470	Assembly, Pantry Cover Support			
8	W10317184	Pan, Crisper (8")	18	W10555437	Bin, Upper Freezer			
9	W10408748	Holder, Produce Filter	19	W10257246	Axle, Roller			
10	W10356844	Control, Humidity	20	W10317289	Basket, Lower Freezer			


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	5	W10649115	Assembly, User Interface	9	W10356017	Ring, Trim
2		Drip Tray	6		Cover, Separator	10	2305235	Assembly, Spigot
	W10300448	White		W10356029	Chromium Frost	11	W10445080	Tube, Water Dispenser
	W10356018	Black	7		Assembly, Single Pad			
	W10356019	Grey		W10433547	White			
3	W10300437	Separator		W10433546	Black			
4		Fascia, Sparsh		W10433548	Grey			
	W10435575	Silver Mirror	8	W10465298	Assembly, Dispenser Wire			
	W10435576	Black						

ICEMAKER PARTS



ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10329003	Clamp, Tube	11	W10435665	Cup, Water Fill	21	W10279866	Assembly, Dual Valve
2	628379	Clip, Thermal Fuse	12	627843	Ejector	22	W10223929	Assembly, Module and Motor
3	W10352217	Clamp, Tube	13	W10122563	Stripper, Ice	23	489478	Screw
4	2181939	Insert, Tube	14	2194712	Support, Housing	24	489136	Screw
5	W10238100	Valve, Inlet	15	2315522	Retainer, Thermostat	25	488208	Screw
6	W10578502	Tube, Water	16	628397	Thermostat (Also Order 542369 Cement Alumilastic)	26	488886	Screw
7	W10237915	Bracket, Water Valve	17	W10001280	Screw	27	628320	Bracket, Ice maker Mounting
8	W10289690	Cover, Ice maker	18	489276	Screw	100	W10632400	Assembly, Ice maker
9	489442	Screw	19	W10474785	Arm, Shut Off			
10	628228	Assembly, Mold and Heater (Also Order 542638)	20	W10309400	Assembly, Ice Maker Wire			

OPTIONAL PARTS

FOLLOWING PARTS NOT ILLUSTRATED

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	511873	White Porcelain (2 oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	606755	Bag
	503695	Cork, Sealer

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White
	4392900	Biscuit/Bisque

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key