


RV213844 REPLACEMENT PARTS LIST

HVAC BASE UNIT COMPONENTS - GAS

PAGE 1 OF 2





RV213844 REPLACEMENT PARTS LIST

HVAC BASE UNIT COMPONENTS - GAS

PAGE 2 OF 2

ITEM NUMBER	QUANTITY	EVANS PART NUMBER	SERVICE PART NUMBER	DESCRIPTION
1	1	RV202085	RV213844	HVAC ASSEMBLY (INCLUDES 2 – 21)
2	1	RV012700	RV219544	PLASTIC CASE, RH TUBES
3	14	HV032812	N/A	ASSEMBLY SCREW, CASE
4	1	HV033498	RV212112	RELAY
5	1	HV033061	RV212093	COLD CONTROL
6	3	RV012416	N/A	ASSEMBLY SCREW, ACTUATOR
7	3	GM131014	N/A	WASHER
8	1	HV038199	HV218965	ACTUATOR
9	1	RV012698	N/A	ACTUATOR MOUNT BRACKET
10	1	RV012699	N/A	SHUTTER DOOR ASSEMBLY *(INCLUDES RV012161 AND RV012162 SEALS)
11	1	RV012163	RV219369	PARTITION, RECIRC DOOR
12	1	RV012706	RV219370	CORE PLATE
13	11.3 FT	BL012116	N/A	FOAM SEAL TAPE
14	1	RV012605	N/A	FOAM PAD, EVAPORATOR
15	1	RV012692	RV219542	COMBO CORE ASSEMBLY (INCLUDES ITEM 19 AND 20)
16	2	RV011162	N/A	O-RING
17	1	RV012708	RV219535	EXPANSION VALVE
18	1	RV012604	N/A	TUBE SEAL, RH
19	1	RV012695	RV219543	LIQUID HOSE ASSEMBLY