


DRAWER

DRAWER



CSA


3" BAND

ELECTRIC CHAISE




BLIND STITCH ON
CHAISE CUSHION

BASEBALL STITCH

BASEBALL STITCH
(ALL ARM STITCHING)



CUT PATTERN
BACK FRAME NO.
BASE FRAME NO.
WOOD PATTERN



ELECTRIC
SWITCH

