





0199




0198



0197

Position ID	Part No.	Replacement	Description
0102	11009058		Induction hotplate
0102	12009080		Sensor-NTC
0103	11032303		Induction hotplate
0103	12009078		Sensor-NTC
0104	12009061		Induction hotplate
0104	12009081		Sensor-NTC
0112	11009074		Lid
0113	11009071		Lid
0121	20000084		Frame
0122	10008077		Cover
0136	11019092		Fixture
0139	20000086		Case-bottom
0141	20000089		Glass ceramic hob top
0145	00636575		Cover
0148	00424665		Spring
0161	00636512		Fixture
0197	00267971		Sealing strip
0197	00604442		Fixing kit
0198	00617227		Screw-set
0198	00636637		Screw
0198	00636638		Screw
0198	10003766		Screw
0199	00618647		Lubricant
0199	00636640		Screw
8701	15000432		Auxiliary tool



Position ID	Part No.	Replacement	Description
0202	11032304		Power module not programmed
0204	11029136		Power module not programmed
0212	11016570	11009108	PC board
0213	12008984		Fan
0223	10003008		Connection piece
0230	10003019		Connection piece
0231	10003024		Connection piece
0240	11032349		Operating module
0241	11008965		Fixture
0260	11032348		Connection piece
0261	00673380		Connection piece
0263	00414692		Connection
0264	00415812		Retaining washer
0265	00416289		Insert
8701	15000432		Auxiliary tool
0202	11033421		Power module programmed
0204	11033420		Power module programmed