





"P" Series Replacement Parts



BL1196-00
BL1197-00



BL1194-00
BL1195-00



BL1198-00
BL1199-00

"P" Series Powered Range Hood

Item	Qty	Part #	Description
1	1	BL1196-00 BL1197-00	Black Lamp Switch (Rocker) White Lamp Switch (Rocker)
2	1	See Table	Fan Switch (Rocker)
3	1	CA0461-02 CD0289-01	Wiring Cover (Rocker switches in nose top) Wiring Cover (Rocker switches in nose front)
4	1	L7318-00	Resistor (2 Speed Fan Only)
5	1	C0120-00	Green Ground Screw
6	5	C0119-00	#8 x 3/8" Sheet Metal Screw*
7	1	BCB0267-02	Lamp Socket
8	1	VA0415-00	#921 Lamp Bulb*
9	1	BCC0246-00 BCC0248-00	Aluminum Grease Filter, Charcoal Grease Filter for Ductless Range Hoods
10	1	BCC0179-00	Lamp Lens
11	1	BCC0245-00	Filter/Lens Retainer
12	1	BCA0472-00	Plastic Damper (N/A for ductless models)
13	1	C0488-00	Damper Lock Spring (N/A for ductless models)
14	2	See Table	Machine Screw*
15	1	See Table	12 Volt DC Motor
16	1	See Table	Fan Blade
17	1	Consult Factory	Blower Housing

*Can be purchased locally

1 Speed Fan (Rocker)

Fan Switch	Color
BL1194-00	Black
BL1195-00	White

2 Speed Fan (Rocker)

Fan Switch	Color
BL1198-00	Black
BL1199-00	White

Air Mover Parts

WHAT YOUR MOTOR LOOKS LIKE

VA0183-00 FAN BLADE	BVC0472-00 FAN BLADE	BVD0216-00 FAN BLADE
#4-40 MACHINE SCREW	#4-40 MACHINE SCREW	M2.6 MACHINE SCREW
VA0164-01 MOTOR	BVC0468-01 MOTOR	BVD0218-00 MOTOR
NO LONGER AVAILABLE USE BVD0218-00 MOTOR & BVD0216-00 FAN BLADE	NO LONGER AVAILABLE USE BVD0218-00 & BVD0216-00	