





RV213193 REPLACEMENT PARTS LIST **DASH PACKAGE** **NEWMAR – 85463 – DIESEL** **SHEET 1 OF 3**



ITEM NUMBER	EVANS PART NUMBER	SERVICE PART NUMBER	DESCRIPTION
1	RV201248	N/A	BLOWER AND DUCT ASSEMBLY (INCLUDES 2 – 16)
2	RV200963	RV218792	BLOWER ASSEMBLY (INCLUDES 2 – 8)
3	RV200964	RV218864	BLOWER MOUNTING PLATE
4	RV011887	RV218811	GASKET – MOTOR PLATE
5	HV036096	RV218762	BLOWER HOUSING – PLASTIC
6	RV011794	RV218863	GASKET – BLOWER
7	HV034738	HV218013	BLOWER WHEEL
8	HV033208	RV218076	BLOWER MOTOR
9	RV201256	RV218919	DUCT ASSEMBLY (INCLUDES 10 – 16)
10	RV201249	RV218920	WELDED DUCT ASSEMBLY
11	RV010561	RV212146	RESISTOR – 4 SPEED
12	RV010934	RV218213	2.50" PLASTIC COLLAR (5 EACH)
13	RV012108	RV218921	FRONT PANEL
14	RV010608	RV212154	BI-LEVEL VACUUM MOTOR (2 EACH)
15	HV030910	HV218542	PUSHNUT – REMOVABLE
16	RV010935	RV218810	3.00" PLASTIC COLLAR (2 EACH)




RV213193 REPLACEMENT PARTS LIST **DASH PACKAGE** **NEWMAR – 85463 – DIESEL** **SHEET 2 OF 3**



ITEM NUMBER	EVANS PART NUMBER	SERVICE PART NUMBER	DESCRIPTION
1	RV010687	RV212220	AIR RETURN GRILL
2	HV027784	RV212314	2.5" DIAMETER ROUND LOUVER
3	BL011836	RV218444	VACUUM TUBE X 68"
4	HV030572	RV218163	VACUUM TANK
5	RV011454	N/A	OWNER'S MANUAL
6	RV201471	RV218967	VALVE ASSEMBLY
7	RV200505	RV218234	VACUUM PUMP ASSEMBLY (INCLUDES ITEMS 8 - 11)
8	RV011185	RV218237	VACUUM PUMP
9	HV033856	RV218236	ADAPTOR – 1/4" TO 1/8" HOSE
10	BL011830	RV218325	1/8" VACUUM TUBE X 1-1/2" LONG
11	RV200506	RV218238	WIRE HARNESS



RV213193 REPLACEMENT PARTS LIST **DASH PACKAGE** **NEWMAR – 85463 – DIESEL** **SHEET 3 OF 3**



ITEM NUMBER	EVANS PART NUMBER	SERVICE PART NUMBER	DESCRIPTION
1	RV201473	N/A	CONTROL PANEL ASSEMBLY (INCLUDES 2 – 16)
2	RV200733	RV218552	CONTROL PANEL HEAD ASSEMBLY (INCLUDES 3 – 14) 02093
3	RV011405	RV218470	KNOB, BLOWER SWITCH 02260
4	RV011407	RV218472	KNOB, TEMPERATURE AND MODE SWITCHES 01969
5	RV011546	RV218565	DECAL (SERVICE PART INCLUDES ITEM 6)
6	RV011541	RV218565	LENS (SERVICE PART INCLUDES ITEM 5) 011270
7	RV011548	RV218564	HOUSING, CONTROL PANEL 08105
8	RV011494	RV218550	MOUNTING BRACKET, POTENTIOMETER 05191
9	RV011415	RV218476	MODE SWITCH 04660
10	RV011493	RV218549	TEMPERATURE CONTROL SWITCH 01893
11	RV011444	RV218479	LAMP SOCKET
12	HV027734	RV218469	BULB, LAMP
13	RV011412	RV218475	BLOWER SWITCH 04355
14	HV010667	RV218468	NUT, BLOWER SWITCH
15	RV012268	RV218975	WIRE HARNESS
16	RV011438	RV218466	VACUUM HARNESS 05231