NEWMAR CORPORATION WARRANTY DEPARTMENT

| | | ECHNICAL | | | | | |
|--------------------------|-----------|---|---------|------------------------------------|------------|-------------|------|
| DATE ISSUED | | MODEL YEAR(S) AFFECTED | | MODEL(S) AFFECTED EXDP / KGDB / | | TSB # | |
| 10/20/08 2005 | | 2005 - 2009 |) | LADB | | 357 | |
| BRAND | | | | | | Түре | |
| .11 | | American Star | | Mountain Aire | | All 🗖 | ТТ 🗖 |
| Cypress | | Dutch Star | | Kountry Aire | | FW□ | CA□ |
| Northern Star | | Kountry Star | | Essex | | D P 🗖 | D B |
| cottsdale | | King Aire | | London Aire | - | | |
| ll Star ME | | Ventana | | Bay Star | | | |
| Air Conditio | oning & H | leating | I | □ Electrical Com | ponents | | |
| Appliances & Accessories | | | I | Exterior Components | | | |
| Cabinets & Furniture | | | I | Interior Components | | | |
| □ Chassis Components | | | l | Plumbing & Bath Components | | | |
| Constructio | n Compo | nents | I | ☐ Windows, Awr | nings, Ven | ts, & Doors | 5 |
| | | | | | | | |
| | | DESCF | | PROBLEM | | | |
| 0 | | nical service information 110 degrees. Potent | 0 | 6 | | 0 | |
| | | | | | | | |
| | | RECOM | IMENDED | SOLUTION | | | |

If you have any questions regarding this T.S.B., please contact a Warranty Service Representative at Newmar Corporation.

Frigidaire Product Bulletin

By design, the freestanding Frigidaire refrigerator (residential style) will not operate properly when indoor air temperatures exceed 110°F (43°C). In addition, operating the refrigerator in these conditions could cause compressor failure which may not be considered warrantable.

Please educate your Sales & Service staff as well as your retail customers of this situation and we would recommend these options:

- Leave the air conditioner set on 80°F or lower if the refrigerator is left running in a vehicle that is not being used.
- If the inside temperature of the vehicle cannot be kept below 110°F (43°C), the refrigerator must be shut off.

Please see the refrigerator <u>Use & Care Manual</u> for complete operation and maintenance instructions.

