

CHANGING AN INTELLITEC CONTROLLER TO A C-STORM CONTROLLER

- 1. Insert the 2 wire (GREEN) & 5 wire (BLUE) connector to the corresponding sockets.
- 2. Cut the ground (GND) wire approx. 4 -6 inches from 5pin plug.
- 3. Connect the J3 wire from Intellitec controller (RED) to existing incoming GND ground to Butt Connector.
- 4. Connect the 4 inch GND wire from plug connector and an additional 3-4 foot wire of same wire gauge to the chassis frame rail existing ground connection.

Chassis Frame Rail Ground

ELLITEC MOTOR CONTROL 10A-35A 470 OHM MOTOR CHASSIS GND NEAR 2 Existing Ground self-tapping screw risien: Revised controller to show GND lug; added chassis By. SJM W/OUT POWER LOCK ARMS GND connection in basement near controller

